



This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

Usage guidelines


Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.


We also ask that you:

- + *Make non-commercial use of the files* We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.
- + *Refrain from automated querying* Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.
- + *Maintain attribution* The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.
- + *Keep it legal* Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.

About Google Book Search

Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at <http://books.google.com/>





100





A
PRACTICAL COURSE
OF
MILITARY SURVEYING,
INCLUDING
THE PRINCIPLES OF TOPOGRAPHICAL DRAWING.

BY
CAPTAIN LENDY, F.G.S., F.L.S., &c.

Fourth Royal South Middlesex Militia.
DIRECTOR OF THE PRACTICAL MILITARY COLLEGE AT SUNBURY.

WITH
AN ATLAS OF FIFTY PLATES,

MOSTLY BY
MAJOR PETLEY,
PROFESSOR OF MILITARY SURVEYING AT THE ROYAL MILITARY COLLEGE AT SANDHURST.

NEW EDITION, WITH MANY ADDITIONAL PLATES, &c.

LONDON:
ATCHLEY AND CO.,
Publishers of Engineering and Architectural Works,
106, GREAT RUSSELL STREET, BEDFORD SQUARE, W.C.
1869.

[The right of Translation is reserved.]



183. h. 16.

LONDON :
SAVILL, EDWARDS AND CO., PRINTERS, CHANCERY STREET,
COVENT GARDEN.

PREFACE.

IN the First Edition of this work allusion was made to the mischief done by the diversity of methods employed in this country for representing ground. Since then, Colonel Scott, R.E., the Examiner in Military Drawing, proposed to modify the horizontal style so as to obtain accurate representation and pictorial effect. His method was accepted, and since 1867 it is exclusively followed in all the Military Schools of the Government.

Eight plates, illustrating this new method, XLI.—XLVIII., have been added to this volume. They will be found to differ but slightly from the eight original plates, XI.—XVII.

The practical part of the work has not been altered, and it remains quite elementary, although sufficient for all field purposes.

A brief sketch of the operations necessary for a trigonometrical survey has been added, without, however, encumbering the volume by the description of instruments of precision, such as the theodolite, circumferentor, &c., which are treated at full length in the "Treatise on Instruments" of Heather.

CONTENTS.

CHAPTER I.

DEFINITIONS.

Topography—Military Surveying—Models—Plans—Military Sketches—Reconnaissance—Geodesy—Geography—Planimetry—Levelling—Scales—Scales employed in Military Surveys pp. 1—6

CHAPTER II.

TOPOGRAPHICAL DRAWING.

§ I. *Conventional Signs of Planimetry.*

Objects to be represented in a Military Plan—Conditions which such a Plan should fulfil—Table of the Signs adopted in the Ordnance Survey—Minute—The Light supposed Vertical—Colouring—Hints on the Drawing of the Signs . . . pp. 7—9

§ II. *Representation of the Ground.*

Conditions to be obtained—*Geometrical Method*—Horizontal Contours—Burr's Experiment—Equidistance of Contours—Profiles and Elevations can be made—This Method is generally accepted—Shading of the Ground—Vertical Light—Difficulties met with—*French System*—Diapason—*German System*—Lehman—*English Systems*—Horizontal and Vertical Styles—*Colonel Scott's Scale of Shade*—*Brushing*—*Oblique Light*—*Perspective* pp. 10—18

§ III. *Features of the Ground.*

Watershed—Basin—Crest—Table Land—Col—Defile—Hills—Counterforts—Valleys—Vales—Ravines—Remarks on Drawing Hachures pp. 19—23

§ IV. *Copy and Reduction of Plans.*

Copying at the same Scale—Order in which the Objects are Drawn—Reduction to a different Scale—How to proceed when the Area is to be reduced in a given proportion pp. 23—25

CHAPTER III.

TRIANGULATION.

Triangulation—Filling-in of the Details—Military Method—Base Line—Form of the Triangles—Length of the Base and Dimensions of Triangles—Two Methods to make the Triangulation, Calculation or Construction—The latter exclusively employed for Military Surveys—Plotting in the Field pp. 26—29

CHAPTER IV.

DISTANCES.

Chaining—Pacing—Riding—Rough Valuation of Distances. Construction of Scales—
Scales of 6 in. and 2 in. to the mile—Scale of $\frac{1}{32175}$ —Scale of Paces—Scales for
Riding—Scale for a foreign plan—Reduction of Distances to their horizontal Pro-
jection—How to Trace or Signal a Direction pp. 30—36

To what account Chaining or Pacing can be turned—To Trace on the Ground a
Perpendicular to the Extremity of a Line which cannot be produced—To find the
Distance between Two Points, one of which is inaccessible—To make an Angle
equal to a given Angle—Through a given point to draw a Line Parallel to a
given Line—How to produce a Direction beyond an Obstacle—How to find the
Distance between two inaccessible Points—To bisect an Angle—To find the
Direction of the Capital of a Work—To find the Height of a Building—To fix
on a Plan the Projection of a Point, having on that Plan the Projections of Two
Lines: or having the Projection of a Line on which the Point stands, and the
Projection of an accessible Point—The Projections of two Points being given, to
fix on the Plan the Projection of a Third, which is inaccessible—To find the
Projections of several Points pp. 37—43

CHAPTER V.

PRISMATIC COMPASS.

Magnetic Azimuth—Bearing—Prismatic Compass; its use—Protractor: its use—To
find the Projection of a Point, knowing those of two others—Method of Intersec-
tion—To find one's place in a Survey—To Survey a Road—Method of Traversing
—Taking the back Angle—To trace the Direction of the Capital of a Work—
Echelle rapporteur Trinquier pp. 48—59

CHAPTER VI.

PLANE TABLE.

Various Descriptions of Plane Tables—Use of the Plane Table—To fix the Projection of
a Point having those of two Accessible Points—Ditto, When one of the two Points
is inaccessible; Ditto, When the two Points are inaccessible—To fix the Projection
of two accessible Points, being given those of two inaccessible ones—The Projec-
tion of three inaccessible Points being given, to find the projection of an accessible
Point—To find one's Place in a Survey—Addition of a Compass to the Plane Table
—Plane Table of Major Pèvre: his Scale pp. 59—68

CHAPTER VII.

SEXTANT AND CROSS-STAFF.

Box-sextant: its adjustment; its use—Vernier—Box-sextant less advantageous than
the Prismatic Compass—Principle of the Box-sextant—Problems it enables to
solve pp. 69—75

Cross-staff: its various forms—Through a given Point to Trace a Perpendicular to a given Line—To produce a Direction beyond an Obstacle—Through a given Point to draw a Line parallel to a given Line—To find the distance between two Points, one of which is inaccessible—Ditto, both Points are inaccessible—To Survey a Polygon or a River—To find the area of a Field pp. 75—79

CHAPTER VIII.

LEVELLING.

Levelling—Clinometer and Box-sextant give the Angle of Elevation—The Difference of Level is then calculated—Tables—French Water-level; its use to measure directly the Difference of Altitude—A Substitute for it—Levelling with a Chain—Levelling with the Plane Table—Clinometer Trinquier; its description—This instrument gives the Angle of Elevation, the Horizontal and the Vertical Distance between two Points pp. 80—90

CHAPTER IX.

MILITARY SURVEYING.

Preliminary Operation—Selection of Triangles—Measure of a Base—Triangulation—Tracing the Meridian Line—Subdivision of Labour—Filling in the Details—Traverse and Intersection—Details—Representation of the Ground—Canvas of Levelling—Preliminary Sketches—Tracing the Contours with a Water-level—Ditto, by means of the Altitudes of the Chief Points—Ditto, by means of the Angles of Depression or Elevation—Memoire pp. 91—102

CHAPTER X.

MILITARY SKETCHING.

A Survey best Introduction to Sketching—Sketching—Hints as to Details—Surveying at Sight—Instruments made in the Field—Itineraries—Sketching from Memory—Sketching from Description—Reconnoitring—Report—Table to Guide in the writing of a Memoire pp. 103—122

CHAPTER XI.

ENSEMBLE OF THE OPERATIONS OF GEODESY.

Measurement of Bases—Triangulation—Measurement of Angles—Levelling—Mapping—Limit of Bases—Reduction of Angles to the Centre of Station—Reduction of an Angle to the Horizon—Correction due to the Refraction—Correction due to the Curvature of the Earth—Levelling with Barometer pp. 123—132

Table of Colonial and Foreign Linear Measures p. 132

Table of Lehman's Gradations p. 133

Circular of the Council of Military Education p. 134

LIST OF THE PLATES.

- I., II., III., IV. Conventional Signs.
V. Chief features of the ground represented by Contours.
VI. Sections of ditto.
VII. Elementary Plan.
VIII. The ground figured by Interpolated Contours.
IX. Another Horizontal Style.
X. The ground of Plate V. figured in the above style.
XI., XII., XIII., XIV., XV., XVI., XVI. (a.) The horizontal style as taught at Sandhurst before 1867.
XVII. A Military Sketch.
XVIII. Ditto.
XIX. A Sketch in a different style.
XX., XXI., XXII. Ground figured in the Vertical Style.
XXIII. Ground of Plate V. in the Vertical Style.
XXIV. Military Sketch in the Vertical Style.
XXV. Ground figured by shading with Indian ink (light vertical).
XXVI. The same, with oblique light.
XXVII. Ground figured in Perspective.
XXVII. (a.) Eye Sketch.
XXVIII. First stage of a Copied Plan.
XXIX. Second ditto.
XXX. Third ditto.
XXXI. The same completed.
XXXII. Reductions of the same.
XXXIII. Specimen of Engraved Plan.
XXXIV. Photo-litho of the English Ordnance Survey (scale 1 inch to the mile).
XXXV. Photo-litho of the French Ordnance Survey (scale $\frac{1}{50000}$)*.
XXXVI. Sketch of a Road in Vertical Style.
XXXVII. Ditto in Horizontal Style.
XXXVIII. Sketch given to the Candidates for admission to the Staff College in 1861.
XXXIX. Ditto in 1863.
XL. A Military Sketch, illustrating Colonel Scott's original Scale of Shade.
XLI., XLII., XLIII., XLIV., XLV., XLVI., XLVII., XLVIII. The Horizontal Style of Colonel Scott, as actually taught.

* It is next to impossible to compare the English and French maps; the English diapacon gives a much darker shading, and its scale is different. In order to compare them properly, the same ground should be represented on the same scale.

ERRATA.

Page	line		instead of	square	read	squares
24	11		"	contour	"	contours
25	1		"	A C' : A B'	"	A C : A B
28	8		"	B A B	"	B A C
32	6		"	perpendicular	"	perpendiculars
44	2 from bottom		"	On the plan	"	On the plan construct
47	2		"	X	"	x
63	3		"	a b	"	b x
63	5 from bottom		"	plan	"	plane
64	2		"	z, x,	"	a, x,
64	11		"	in line the edge	"	in line; the edge
71	7		"	(n-1), D	"	(n-1) D
71	7 from bottom		"	12°-g'	"	12° g'
72	2		"	exceed or fall short of 360°	"	exceed 360°
83	4 from bottom		"	a d b c	"	a d, b c
96	2		"	outline	"	outlines
100	5 from bottom		"	(Euclid, p. lvi.)	"	(Euclid, lib. lvi.)
101	2 from bottom		"	the less	"	the least

A PRACTICAL COURSE OF MILITARY SURVEYING.

CHAPTER I.

DEFINITIONS.

(1.) *Topography* (surveying) is the art of describing a limited part of the surface of the earth, so as to give a good idea of its configuration and the resources it presents.

The purpose of *military topography* (military surveying) is to describe clearly the ground and position of all objects scattered over its surface that have any military importance. These objects are either natural, as mountains, hills, valleys, rivers, marshes, &c. ; or artificial, as houses, enclosures, walls, fortifications, &c. All are of some military importance, since they can modify the action of troops.

The description of the surface of the earth was originally made in writing, by a greater or less number of notes : these were rather difficult to use. Imitative drawings came into use much later.

(2.) The ground can be represented in two manners : by models or by plans.

Models are made of plaster or wood, and, like a sculpture, present in a small compass the exact image of the elevations and depressions of the ground. They are expensive, take much time, and their size and weight render them unavailable for field purposes. Their sole advantage is to represent the ground to persons not familiar with the reading of maps. Of such use are the models of Sebastopol, Waterloo, &c., at the Royal United Service Institution.

A *plan* or map is a figure which by means of a few conventional signs represent all the natural and artificial objects above alluded to in their relative position: Unlike relieves, a plan can be taken into the field, and is indeed an indispensable item in war.

By means of plans the General prepares all his operations, battles, sieges, marches, encampments, entrenchments, &c. ; by their help the great deeds of war are put down in records which afford to history the most valuable materials, and to the art of war the most useful lessons.

(3). Topography is an indispensable complement to all the military sciences, fortification, tactics, &c., since the application of their principles entirely depends on the nature of the ground ; and as it is most important for an officer to appreciate at a glance the distances, slopes, and in general all the mutual relations of the various parts of a field of battle, he should remember that this *coup d'œil militaire* is only acquired by the practical study of Topography.

(4.) When a plan is intended to serve as a guide to prepare constructions on the ground, such as fortifications, buildings, &c., it is made with accuracy, and the survey is called regular. When, however, a less accurate description is needed, a survey more or less rapid is made according to the purpose in view ; the survey is then called *irregular*, or *reconnoitring*, and the plan is named a *military sketch*.

In regular topography the execution of the plans requires precise methods, good instruments, and time ; but in irregular surveys and reconnoitring, instruments of a less accurate description are sufficient : sometimes they may be dispensed with ; thus military sketches are made at sight, from memory, and even from mere indications and reports.


Military surveying is very seldom regular, because while time is always precious in the field, instruments are not always to be had, and, above all, because a great accuracy is not needed. The plans of fortification, those of attacks in a siege, demand, however, some precision. Regular surveying should be studied first, because it is only through a thorough acquaintance with its principles and methods, together with a fair amount of practice, that an officer will be able to make a military sketch expeditiously and without instruments.

(5.) Topography describes limited parts of the surface of the earth

only: when those parts exceed sixty miles in length, more accurate methods are resorted to, and form the province of *geodesy*. This science enables us to describe considerable tracts of land, such as kingdoms, &c.; it furnishes the materials for *geography*, and gives to topography the exact position of the important landmarks. By means of calculations and practical operations it determines with great precision the relative position of the chief points of a country, such as summits of mountains, intersections of valleys, steeples of churches, &c., leaving aside all details. Topography, on the contrary, represents all the details lying between two or three of these points, and its operations are exclusively practical.

(6.) The plan of a certain extent of ground is a figure similar to the projection of all the points of that surface on a horizontal plane; a projection being the foot of the perpendicular drawn from a point to the plane. In topography this plane is tangent to the surface of the earth, and the earth being spherical, the spherical segment A B C cannot

FIG. 1.



be represented exactly on the circle a b c. As, however, the error does not exceed three yards in sixty miles, it matters but little if we consider the earth to be plane in topography. When, however, the surface to be described is large, the sphericity cannot any longer be neglected, and geodesy takes it into account in the survey of a country.

(7.) Since topography describes both the objects lying on the surface of the earth and the undulations of that surface, it may be divided into two parts: *planimetry*, or the making the plan of those objects; and *levelling*, or representing the ground itself. Should the

ground be exactly level, topography would consist of planimetry only.

In order to represent on paper the various details of the surface of the earth, a few *conventional* signs have been adopted, and the student should, first of all, render himself thoroughly familiar with their meaning, and acquire some practice in drawing them. When he knows them so as to *read* or *copy* a plan, he has mastered one of the essential parts of topography. Before passing those signs in review we must say a word or two about the scale of the plan.

(8.) The representation of a given surface of ground can be made of different sizes according to the end in view, it being clear that the greater the accuracy required the larger the drawing must be.

The size of a dimension of the plan compared to that of the ground which it represents is called the *scale* of the plan. Thus, if a road one mile in length occupies but one inch in the drawing, the scale is that of *an inch to the mile*. If a wall 600 yards long is represented by a line one inch long, the scale is that of an inch to 600 yards.

Sometimes this expression is reversed, and we say, the scale of 12 chains to the inch, of 4 miles to the inch, &c.; it signifies that an inch of the plan represents 12 chains, 4 miles, &c., on the ground.

It may also happen that the scale be indicated by a representative fraction, such as $\frac{1}{2000}$ or $\frac{1}{40000}$, &c.; it implies that the dimensions of the plan are 2000, 40,000, &c., times smaller than the corresponding ones on the field.

We may readily pass from one form to the other; for instance, the scale of one inch to the mile may be called that of $\frac{1}{63360}$, since a mile contains 63,360 inches; the scale of 12 chains to the inch, or that of $\frac{1}{9504}$, signifies the same thing, because 12 chains contain 9504 inches. Conversely, a French plan on the scale of $\frac{1}{40000}$ is a plan on the scale of 1 inch to 40,000 inches.

(9.) The selection of the scale at which a plan is to be made is not altogether arbitrary, for it depends, on the one hand, upon the degree of accuracy required in the representation of the country, and on the other upon the dimensions of the paper at disposal.

If we have to survey a distance of three miles, it is evident, that if our sheet of paper is only 24 inches long, we cannot employ a scale

larger than 24 inches to 3 miles, or 8 inches to the mile; because, with a greater scale there would not be sufficient room to represent the whole of the ground. Any smaller scale, such as 4 or 2 inches to the mile, could be employed.

Still, in employing a scale much smaller than that of 8 inches to the mile, we might meet with another inconvenience, since small objects could not be represented. The accuracy required must then guide us. At the scale of 1 inch to the mile, for instance, a field 10 yards in length would be represented only by $\frac{1}{176}$ of an inch, a dimension much too small to be easily appreciated or represented. This scale is, therefore, too small if we are expected to give every detail within 10 yards. What scale, in this case, should be adopted? In answer to this, let it be observed, that in supposing a plan to be mathematically true, we unavoidably commit in reading it an error due to the imperfection of our senses. We cannot appreciate a division smaller than the $\frac{1}{16}$ part of an inch, for our eyes cannot perceive if the points of the compasses are within $\frac{1}{16}$ of an inch too near or too far apart. This uncertainty of reading becomes $\frac{1}{16}$ of an inch, or 17 yards, at the scale of an inch to the mile. Therefore, if the plan ought to permit us to read every dimension within 10 yards, the scale should be such, that $\frac{1}{16}$ of an inch represents to the utmost 10 yards, or 1 inch represents 1000 yards. To read within 35 yards, the scale should not be under $\frac{1}{16}$ to 35 yards, or 1 inch to 3500 yards.

When a plan is given, its scale at once shows with what degree of exactitude it can be read; thus, a plan at the scale of 4 miles to the inch gives us a distance on the ground within $\frac{1}{16}$ miles, or 70 yards.

We have taken for granted that the $\frac{1}{16}$ part of an inch is the smallest dimension which we can appreciate, and, consequently, draw, although divisions of $\frac{1}{32}$ of an inch can be obtained. In topography, however, this accuracy becomes an illusion, for the paper on which plans are made contracts and expands so much under the influence of heat and moisture that the valuation of small dimensions depends upon the state of the atmosphere: $\frac{1}{16}$ being already very small.

(10.) In military surveys a great accuracy in the details is not expected, as it is not required to give *very* exact dimensions of

encampments, roads, &c. It is customary to employ the following scales :—

24 inches to the mile for plans of a fortress or field works.

12 inches for the plan of attacks on a fortress, of defensive positions, camps, &c.

6 inches for the topography of a district, the march of armies, sketches of roads, encampments, &c.

4 inches for larger surfaces, in reconnoitring, &c.

1 inch is adopted for the engraved sheets of the ordnance survey.

In France the ordnance map is engraved at the scale of $\frac{1}{100000}$.

When smaller scales are employed, the plans are called maps, or geographical maps.

Every plan or map should bear the name of the scale at which it has been made.

CHAPTER II.

TOPOGRAPHICAL DRAWING.

§ I.

Conventional Signs of Planimetry.

(11.) A military plan should represent faithfully all the objects that possess some military importance or interest ; such as—

Communications :—railroads, high roads, cross roads, bridle-paths, foot-paths ; rivers and canals, with their accessories, such as dams, towing-paths, &c. *Buildings*, including houses, farms, castles, churches, &c. ; they have a double importance as habitations and defensive positions. *Enclosures* :—walls, ditches, hedges, palisades, palings, &c., which constitute a cover and an obstacle for troops. *Divisions of Country* :—ploughed lands, gardens, orchards, vineyards, and meadows, which produce food for men and cattle ; woods, which furnish fuel and material to construct defensive obstacles with, and whose border itself is a capital line of defence ; fallows, or uncultivated land. Besides these, all objects should be put down which, by their peculiar position, might serve to guide or rally troops, such as crosses, fountains, &c.

(12.) The first condition which a military plan should fulfil is *accuracy*, the second, *clearness*, the third, *simplicity*. Since it is intended to serve for the combinations of the General, and for the movements of troops, it is very important that it should be as faithful as possible ; and in order that all officers, even those who have no artistical turn, should easily draw and represent the various objects, and otherwise thoroughly understand a plan ready made, the conventional signs adopted to represent the objects alluded to should be clear and simple.

(13.) Plates I., II., III., and IV. contain the signs generally employed. They are partly given by Williams's Practical Geodesy, as the signs employed by the commissioners of tithes. Beginners should draw them frequently until they know them by heart ; first in pencil, next in ink. On scales of 4 or more inches to the mile, every object is represented according to its real size, except trees, which are generally made larger ; but on small scales the roads and canals are made wider than they really are, because they would otherwise be scarcely visible.

(14.) The plan actually executed on the ground, or "minute" as it is called, is done in pencil, and it is necessary to draw it carefully in case time should fail to ink it. This habit of making the pencil lines pure and strong will enable a beginner to survey more rapidly, and more accurately, inasmuch as he will not have to do twice the same operation, which often happens when, the minute being carelessly executed, some details are rubbed out. As soon as we return home we ink that minute with Indian ink, and, if possible, colour it. Should there be no time to ink a drawing, the pencil may be fixed by stretching the paper on a board, and washing it with a mixture of water and milk.















(15.) Although the light is supposed to be vertical (22), it is usual to make an exception for rocks, buildings (when the scale is less than 4 inches to the mile), water, woods, trees, and rivers when wide enough to be figured by two lines. For these objects we suppose the light coming at an angle of 45° from the left-hand corner of the plan. The thick lines render the plan more intelligible, by singling out, as it were, these objects, which are very important in a military point of view.

(16.) With regard to colours, they are employed as follows:—

Crope, yellow: *Gravel*, dots of burnt sienna over a wash of yellow ochre: *Heath*, purple: *Marsh*, horizontal light-blue patches running into green: *Meadow or Pastures*, light green: *Ploughed land*, brown: *River*, dark blue: *Road*, burnt sienna: *Sand*, light yellow ochre: *Sandbanks under water*, as sand with a little red: *Stone and brick buildings*, carmine: *Trees in masses*, yellowish: *Trees single*, dark green: *Uniform*, colour of the uniform: *Water*, blue, with shading on the shore: *Wooden buildings*, sepia.

(17.) The list of conventional signs we have given is by no means complete, but it is quite sufficient for ordinary purposes. We might add a few military signs.

FIG. 1

	<i>Artillery</i>		<i>Fence</i>		<i>Military Post</i>
	<i>Boundary</i>		<i>Railroad</i>		<i>Passable</i>
	<i>Intervall</i>		<i>Shelter</i>		<i>Impassable for Artillery</i>
	<i>Talott</i>		<i>Command de front</i>		<i>Impassable for Infantry</i>
	<i>Water</i>		<i>Front or position of interest</i>		

When, however, objects are met with in a survey for which we do not know of any conventional sign, we make in the margin of the drawing a list of the peculiar signs which we adopt for the occasion.

(18.) We shall conclude this section by some hints on the drawing of conventional signs.

Roads should always be drawn towards the draughtsman, to insure to their sides an equal thickness throughout. The chief thing to keep in mind is the parallelism of these sides, as roads generally retain the same width except near the entrance of towns, where they widen, and in mountains, where they become narrow. The parallelism can only be obtained by drawing the left side first to serve as a guide for the right one.

Railroads, being chiefly straight, are better drawn with a ruler; the two sides should be exactly parallel and rather thick; they are always narrower than roads.

When two or more roads meet to form a crossing, the sides should not intersect at an acute angle, but should be rounded off.

Rivers have the side nearest to the light made thicker. When wide enough they are filled with thin lines, parallel to the winding of the banks, kept closer near the sides.

Lakes, ponds, and seas are drawn in the same manner, and the thin lines may be either horizontal or parallel to the shore.

There are a great many ways of representing trees and woods. In engraved plans (Plate XXXIII.) they are done as in the conventional signs. Sometimes on the sides of roads they are figured by thick dots. In sketches, woods are represented in patches somewhat as in landscape drawing, the light being, as usual, supposed to come from the upper left-hand corner.

Gardens are enclosed by walls or hedges; the interior is divided into small squares, with white spaces to figure the alleys, and the squares are filled with etchings.

Buildings, when not coloured red, are filled with etchings, but on a scale less than 6 inches to the mile they are made quite black. When filled with etching, the sides farther from the light are made thick.

§ II.

Representation of the Ground.

(19.) When the ground is horizontal, the signs which we have given are quite sufficient to represent the country by the outline and relative position of every object; but when the ground is no longer level, new signs become indispensable to complete the plan, so as to make it convey exact ideas of the hills, valleys, ravines, and other undulations of the surface. It is most essential that, by means of such plan, an officer should at once be able to ascertain the position of commanding points, and decide whether a spot is accessible or not to cavalry and infantry.

A plan should therefore fulfil these two conditions:—

1. Represent the ground so as to enable us to ascertain the relative height of the different points, and to judge of the nature of the slopes.

2. Give a figure of the ground that will speak to the eyes.

The first condition requires geometrical methods, whilst the second can only be obtained by combinations of shades.


(20.) The geometrical method consists in supposing the ground intersected by horizontal planes: the projections of these intersections, or *horizontal contours*, are then transferred to the drawing at their reduced size.

To understand the principle, let us make the experiment described in Burr's treatise on surveying.

Procure a stone somewhat resembling a hill, as may frequently be found; fix it with clay to the bottom of a box provided with a plug-hole, and sufficiently large to leave a space free between the stone and its case. Fill the box with water stained with Indian ink, and let it off, by means of the plug, about a quarter of an inch in depth at several times, allowing sufficient intervals for the fluid to stain the stone in that plane, 4, 3, 2, 1, it has fallen to at the last abstraction. These stains will present a series of horizontal lines or contours, 4, 3, 2, 1, all round the surface of the stone; and if we examine the stone thus prepared, looking down upon the top, we shall see that the steepness

and the flexures of its sides will be accurately marked by these contours, which might be said to form a scale of relative steepness.

FIG. 3.



The level of the water constitutes a horizontal plane, therefore those contours are the intersections of the stone by parallel horizontal planes.


(21.) What is said of a stone may be said of a hill or of any surface, and those horizontal contours will give us a geometrical representation of the ground.

But if we come to suppose the horizontal planes of section to be equidistant, we can at once, being given the altitude of one point and the equidistance, find the altitude of any point. The inclination of the slopes may also be found by dividing this equidistance by the perpendicular common to two consecutive contours.

A profile of the ground in any direction can also be obtained: the section of the ground along the direction AB , for instance, is found (Fig. 4) by carrying on any line CD , distances Ca' , Cb' , &c., respectively equal to Aa , Ab , &c., and drawing through those points a' , b' , &c., perpendiculars representing the altitude of the contours a , b , c , &c.: the lines that connect the extremities of those perpendiculars figure

the section. Elevations may also be drawn (see Plates XXI., XXII.) by the usual method of geometry.

FIG. 4.



By diminishing the equidistance, it is clear that the description of the undulations can become very accurate, and almost mathematically exact; it will therefore vary with the scale of the plan and the nature of the country surveyed; the larger the scale, the smaller the equidistance.* This method of representing the ground answers the first condition which a plan should fulfil, and is now adopted everywhere for engineering purposes.

(22.) The second condition, as we stated, can only be obtained by

* In the Irish survey of 6 inches to the mile, it was 50 feet for cultivated parts and 100 feet for mountainous and barren districts. In France, as a rule, the ratio between the equidistance and the denominator of the scale is constant, and $= \frac{1}{10000}$, and a great advantage is thereby gained, since at whatever scale a plan is made, the same inclination will always be represented by contours equally distant. At the scale $\frac{1}{10000}$, the sections are thus 5 metres apart; at $\frac{1}{20000}$, 10 metres, and so on. In exceptional cases only is this ratio altered. Thus, for the almost level plains of Champagne, the Ordnance Survey adopted the ratio of $\frac{1}{20000}$, giving an equidistance of 5 metres, at the scale $\frac{1}{10000}$.

combinations of shade; and if the conventions we adopt in order to gain this object are made to depend upon the principle of the horizontal contours, we shall obtain the very important result of combining accuracy with expression.

Now, when we gaze upon the surrounding country, the effect of perspective presents to our eyes the apparent, instead of the real, forms; the representation should therefore be made as viewed from a point vertically above; but even then, if the sun is shining, the features will differ in the afternoon from what they were in the morning; and the effects of light and shade will not be in constant accordance with the true form.

For these reasons we are led to suppose the ground illuminated by vertical light, as happens in a cloudy day, and if, then, we imagine ourselves placed vertically above the surface to be represented, we shall perceive, as in a model, that the more level a part is the brighter it is, and the steeper the acclivities of a hill, the darker they appear. The shade is thus proportionate to the steepness of the slopes.


(23.) This effect of shade might be produced by adapting the equidistance to the scale and to the nature of the ground, so as to have contours close enough to give a shading; but the tracing of those contours on the ground would be too long for military purposes. If, on the other hand, we insert a sufficient number of lines between a few contours determined by levelling, as in Plate VIII., the ground is not faithfully represented: the surface between two such contours has not always a uniform slope, and the space between two contours of the drawing would be a mean surface either enveloping or intersecting the real one. The execution would be tedious and difficult.

Hence methods have been devised, some having regard to expression only, others combining expression with accuracy. We may classify them under three heads, the French system, the German system, and the English system.

(24.) In the *French system* the hachures are traced perpendicular to the contours, so that the equidistance compared with the length of these hachures will at once give the ratio of the slope. The original contours must, therefore, be preserved on the plan, and the proper effect of light and shade is produced as follows:—

M N, M' N', (Fig. 5) being the contours given, the hachures a b, c d


FIG. 5.



are drawn at a distance, $a c = a b$; the square they form is then divided into two equal parts by $a' b'$, and the rectangles $a b'$, $a' d$ arising therefrom are again divided into two. By this process the hachures are at a distance from each other $= \frac{1}{4}$ of their length, and in the practice the etching is thus expeditiously done.


Should not the contours be parallel (Fig. 6) the hachures are drawn so as to meet them at right-angles.

FIG. 6.



This, however, becomes difficult when the contours are far apart, and beginners will find it more easy to pencil intermediate contours in sufficient number to have them nearly parallel, and the hachures are afterwards kept at the proper interval. When the distance between the contours is very small, it becomes impossible to draw three hachures in the square; they are then made thicker and kept at equal intervals. The effect of shade they produce will thus harmonize with those of less rapid slopes. This should be done as soon as the


FIG. 7.



distance of the contours is less than about $\frac{1}{16}$ of an inch, and the smaller this distance the thicker the etched lines should be.

(25.) In order to preserve on the drawing the traces of the original

FIG. 8.



contours, which are always useful to find altitudes, the hachures of a slice should not be the continuation of those above (A), but should be made to correspond to the intervals of the slice immediately above; and to avoid the bad effect (B) produced by lighter spots, they should be exactly terminated at the contour (C). (Fig. 8.)

(26.) In order to secure an uniformity of shade for all plans, scales of thickness or *diapasons* have been adopted. In the diapason of the French Ordnance Map (Fig. 9) the ratio of black to white is equal to the tangent of the slope multiplied by $\frac{1}{4}$. For a slope of 45 degrees the proportion of black to white is thus 3 : 2. All slopes steeper than 45° are represented as escarpments.

The French system, we have said, combines accuracy with expression, but is not expeditious. It is the best for engraved maps. (See Plates XX., XXI., XXII., XXIII., XXX., XXXI., XXXII., XXXIII., XXXV.)

(27.) In the *German system* the hachures are also perpendicular to the normal contours with or without reference to their equidistance. In the system of Lehmann, no regard is paid to the equidistance, and the slopes are measured by the angle they form with the horizon. The diapason of Lehmann (Fig. 10) gives, therefore, the

FIG. 9.





FIG. 10.



length and thickness of the hachures from 5 to 6 degrees up to 45 degrees.* The latter slope, being impracticable to armies, he represents by absolute black. The ratio of black to white is equal to the ratio of the angle of a slope to its supplement to 45 degrees. Thus, for the slope of 35 degrees, the thickness of the hachures is so regulated as to give a tint in which the black is to the white as 35 : 10 or 7 : 2. In this method the features of the ground are strongly marked, but the tints are too dark, and it is often difficult to read the small writing and see the details.

In other German diapasons the maximum of shade is taken for 60 degrees, but these methods requiring the measurement of every angle are too long in practice.

(28.) *English systems* are of two kinds; the horizontal style and the vertical style, both of which had till lately only expression in view.

In the horizontal style the ground was figured by horizontal strokes more or less thick and close, and the altitude of the chief points was given in figures. Plates IX., X., and XIX. illustrate two varieties of this method, which leaves a wide margin for artistic skill.

From XI. to XVII. we give the series of progressive plates used by the cadets of Sandhurst before 1867. They are a most excellent imitation of nature, and will be found not to differ materially from the new method.


The vertical style in this country has only been employed to obtain

* See Table. Page 133.

expression, and it is not more accurate than the above style, and requires more time. Plate XXIV. is part of the military sketch made in the Crimea by the officers of the Quartermaster-General's Department. Sometimes the vertical hachures are inserted between horizontal contours, but without any law and any regard to equidistance. (See Plate XXXIV.)

The horizontal style, with some modifications proposed by Colonel Scott, R.E., has been exclusively adopted in all the military schools of the Government since 1867. If we refer to the plates XI. to XVII. we must admit that they possess great pictorial effect; but as the original contours have disappeared, we obtain expression, but not accuracy. To remedy this, Colonel Scott retains the original contours, and represents them by dotted lines. (See Plates XLI. and XLVIII.) His Diapason (Fig. 11)

FIG. 11.



was obtained from micrometric measurements from good specimens of drawing.

Having for object to make the weakness inherent in the means of representing relief least felt in the representation of those slopes which are of most importance to the tactical movement of armies, Colonel Scott took the scale of gradations of Lehman (page 133) as guide, and modified the vertical distance at which dotted contours are to be shown, according to the slope and to the scale.

Thus, with the scale of six inches to the mile, the dotted contours are shown at the vertical distances of—

- 25 feet for all slopes below 5°
- 50 „ „ slopes from 5° to 10°
- 100 „ „ „ „ 10° to 20°
- 200 „ „ „ „ 20° to 40°

With the scale of 3 inches to the mile, these distances would respectively be 50, 100, 200, 400 feet (see page 134).

This method is far less simple than the French system, since in the same drawing the distance between the contours is liable to vary.

There will, however, always be two defects in all the varieties of horizontal style. The roads, in hilly ground, deviate but little from the horizontal plane, and are not easily distinguished from the horizontal strokes to which they remain parallel. Again, the extreme strokes at the summit and base of a hill cannot be melted into the soft appearance of natural shade.

(30.) Besides these three systems, there are other methods of shading hills. Brushing with Indian ink is one of them; but it is not susceptible of great accuracy, and is only employed for rough sketches.

To give more accentuation to the features, oblique light has been had recourse to, but it is impossible to represent the real steepness of a slope, since the same slope may be placed in a thousand different positions as regards the direction of light: hence the same slope is differently shaded; it must also be observed that the horizontal surface having to be shaded, the effect is no longer natural.

Plates XXV. and XXVI. are examples of shading extracted from the course of Mr. Bardin, lately Professor of Topography at the Imperial Polytechnic School of France.

Perspective has also been tried in combination with a horizontal projection, as may be seen in old plans (Plate XXVII.), but this method of bird's-eye view drawing is too inaccurate, and it is now confined to those popular maps which are published for the million in time of war.

§ III.

Features of the ground.


(31.) The undulations of the ground may be reduced to a few fundamental forms, whether we consider a large extent of the earth's surface or a small area. Looking at a continent or an island, we observe that the ground rises from the shore up to a chain of mountains, which separates the whole surface into two general slopes or *watersheds*. Each of these watersheds is subdivided into secondary surfaces by chains either perpendicular or oblique to the first. The declivities of the adjacent chains include between them a valley. In the same manner the branches running from these chains contain valleys of less dimensions, shedding their waters in the principal valley; while they themselves receive the tributaries of the concave surfaces formed by the minor subdivisions of the branches. The *ensemble* of all the valleys which empty their water into the sea by the same mouth constitutes what is called a *basin*.

(32.) The chains of mountains vary much in character. Sometimes the two declivities of a watershed meet on a line well defined or *crest*; sometimes they are connected by a flat surface at a greater or less altitude, called *table-land*, or they may be united by two counter-slopes, enclosing lakes without outlets.

(33.) The crest of a chain or *watershed-line* is generally formed of a series of summits, between which depressions, more or less deep, establish communication between the opposite sides, forming what is called a *col* or *pass*.


A *col*, properly speaking, may be defined the highest part of the intersection of two convex surfaces; it is therefore the origin of valleys, and is horizontal.

FIG. 12.




When the col is long and the adjacent heights steep, it becomes a *defile*. The defile, however, may also be found along the base of mountains.

FIG. 13.




(34.) The name of *hills* applies to mountains of minor elevation, more or less conical, and without any apparent crest.

FIG. 14.




Counterforts (croupes) are indentures found in ranges of hills ; their flanks belong to two adjacent valleys.

FIG. 15.




(35.) A *valley* is the concave surface formed by two declivities or flanks; the line $m\ m'$ of less inclination according to which the slopes meet is called the *thalweg*.

FIG. 16.




When the thalweg is but slightly sloping the valley becomes a *dale*.

FIG. 17.



When the flanks are very steep and close they form a *ravine*.

FIG. 18.




In Plate V. we have combined these chief undulations:—thus A, *a, a, a*, are cols; G, G, defiles; B, B, *b, b*, hills; C, C, C, counterforts; D, D, valleys; E, E, vales; F, F, ravines; H, H, table-lands.

(36.) In drawing the hachures between the horizontal contours, we should pay attention to the following remarks:—

The extreme hachures of a slope should be terminated as fine as possible, in order to render softer the melting of the shade into the white of the paper, this conformably to nature, where we see no slope beginning or ending abruptly.

No hachure should be drawn on the direction itself of a thalweg or a watershed-line, because a continuous line would strike the eye unnaturally, as those directions have the least inclination. For a similar reason, in ravines the extreme hachures of the flanks should not meet, but should end in a fine point.

FIG. 19.



In a col the little horizontal table-land is left in blank, and it is limited by drawing the intermediary contours *mn*, *mq*, *qp*, *pn* (Fig. 19)

on which we arrest the point of the extreme hachures. (See Plates XX., XXI., XXII., XXIII.)

(37.) With the rules laid down we are enabled to figure *precisely* the forms of the ground, since the direction of the hachures indicates that of the slopes, whilst their length or distance compared to the *equidistance* permits us to measure the real inclination of the latter. The acclivities have been divided into three classes: those practicable for carriages and inclined to the horizon at not more than 15° ; those practicable for cavalry limited to 30° ; and those practicable only for infantry and limited to 45° . From what precedes, the student will easily perceive on a plan to which class belong the various undulations thereon figured. When the length of the hachure is less than 3 or 4 times that of the *equidistance*, the slope is no longer passable for

FIG. 20.



artillery. When it is less than twice the *equidistance*, the acclivity is too rapid for cavalry, and when both lengths are equal, we know that it is the steepest slope practicable for infantry.

§ IV.

Copy and Reduction of Plans.

(38.) The first step in Topography is to become thoroughly acquainted with the drawing of plans, a knowledge only acquired by practice. Copying plans ready-made renders one familiar both with the conventional signs and with the ordinary features of the ground. This part is the most difficult; but once mastered, surveying becomes comparatively easy.

(39.) When a plan is to be copied on the same scale, its surface is divided into squares or rectangles (Plate XXXI.), which will be so much the smaller as the details will happen to be more minute. An equal frame is then drawn, and its surface is divided into the same number of squares as the model (Plate XXVIII.). The details are then copied


square by square. It is advisable to avoid the use of compasses, and to transfer everything at sight, for it is the only way to learn how to draw rapidly and accurately. Should a square contain too many details, the diagonals may be drawn to give further assistance, or its surface may be subdivided into smaller squares. If the model must not be soiled, we cover it with glass, and trace the square on the glass. We begin with the pencil and draw the roads, rivers, buildings, walls, gardens, rocks, hedges, &c.; then we ink these details in the following order:—roads, rivers, buildings, walls, footpaths, gardens, ditches, direction of hedges, divisions of culture, and rocks.

When this is done, we trace in pencil the horizontal contour (Plate XXIX.). Next we shade the hills, either in the horizontal or vertical style (Plate XXX.). The copy is afterwards completed by figuring the woods, marshes, meadows, or colouring them, as the case may be. The names are then written, together with the altitude of the chief points, and the scale is either made or named under the frame.

(40.) If the copy is to be made on a different scale, say twice smaller, a frame is drawn with sides twice smaller than the model, and its surface is divided into the same number of squares. We proceed then as before, with this exception, that we copy one contour out of two, three, four, &c., when the new scale is twice, three times, four times, &c., smaller.

(41.) If the area of the copy must bear a certain ratio to that of the given plan, say $m : n$ for instance, we proceed as follows:—Draw the two

FIG. 21.



lines CD, DB , so that (Fig. 21) $CD : DB :: m : n$. On BC describe a


semicircle, erect DA perpendicular to BC , then $AC' : AB' :: m : n$. On the direction AB take AH equal to the side of the model, draw through H a parallel to BC , and AK will be the corresponding side in the copy. The second side will be found in the same manner. Having then traced the frame, we divide its surface in the same number of squares as the model, and proceed as usual. The scale of the copy is easily obtained. Take AC' equal to one inch, draw $C'B'$ parallel to CB , and the distance AB' , measured on the scale of the model, will show what one inch represents in the copy.

CHAPTER III.

TRIANGULATION.

(42.) We have said (6) that planimetry consists in making a reduced image of the projections of the various points of the surface of the ground. In practice, however, we make a selection among these points, and begin by considering only the chief ones, such as steeples, chimneys, isolated trees, and other objects easy to recognise at all times, and we imagine them united by straight lines. The projections of those lines constitute a series of triangles forming a sort of netting (canvas) (Fig. 22), between the sides of which all the other details are contained ;

FIG. 22.




and the first problem of planimetry, *contained* in the 18th proposition of Euclid (lib. vi.), will be to make a figure similar to that *canvas*, an operation called *triangulation*: the second problem will again be to make figures similar to those contained in these triangles, an operation called the *filling in of details*.

Thus, the points A, B, c, D, being projected in a, b, c, d, on the horizontal plane (Fig. 22), the figure a b c d is called the *canvas*, and all that is contained in every one of the triangles, a b c, c b d, &c., constitute the details.

It is readily understood that the triangles of the *canvas* must be more or less numerous according as the scale of the plan is small or great, so that the details they contain may be represented afterwards in their relative positions without any appreciable error.

(43.) Since, to construct a triangle, we require to know either three sides, or two sides and one angle, or one side and two angles, it follows that three different methods may be adopted to make a survey. In military topography, however, where expedition is a most essential condition, the methods founded upon the measure of three sides, or of two sides and one angle, are rejected as too long, and the following process is preferred (Fig. 23):—A side, A B, is first measured ac-

FIG. 23.




curately, and its projection is drawn at the scale in a b; then in observing the angles c A B, A B C, the elements of the triangle A B C are obtained and a b c is constructed on a b, similar to A B C. The sides A c, B c, being thus known, we go on measuring the angles

$D A C$, $A C D$, and the triangle $a c d$ is made similar to $A C D$. Again, the angles $C D E$, $E C D$, furnish the triangle $c d e$; and so on, measuring the angles.

This line, $A B$, the only one we measure, is called the *base*. It is selected, as much as possible in the middle of the surface to survey, and such that from its extremities several important points may be seen. In that manner several angles may be observed at a same station: thus while at A , the angles $B A C$, $C A D$, $D A H$, $H A B$, $B A B$, are measured.

(44.) The form of the triangles is not arbitrary, they should be as nearly equilateral as possible, for if an angle were very acute the slightest error in the measurement of the others, in A for instance (Fig. 24), would cause a great difference in the position of the vertex

FIG. 24.



c . Besides, it is very difficult to see exactly where two lines meet at so small an angle. The equilateral form possesses the further advantage of covering a given surface with a less number of triangles, and thereby simplifying the labour.

(45.) The maximum length of their sides, as well as that of the base, depends upon the approximation with which the angles are measured, and upon the scale adopted. The students acquainted with trigonometry will find the length by means of the formula $l = \frac{\epsilon}{2 \sin \alpha}$ in which l represents the length, and ϵ the error depending on the scale or uncertainty of reading (9), and α the error committed in observing the angles, varying with the instruments employed. We give a few results at the end of the chapter.

(46.) Starting from a base, we have said that we draw triangles similar to those of the ground by means of the angles: this can be done either by calculation or construction. Trigonometry enables us, when knowing two angles and one side, to calculate every dimension of a triangle. Having, therefore, measured the base and all the angles, we

can calculate all the sides, and then draw them at the scale by the process of geometry. But this method, certainly the most accurate for surveys of importance and precision, is altogether set aside in military surveys on account of the time it requires. The second mode, which is the one that should be adopted, consists in laying down or protracting the angles as soon as they are measured.

(47.) We need no field-book to write down the various measures, as is often recommended, but we at once draw or *PIOT*, as it is called, what we observe. The only book that we may carry will serve to take note of the statistical, political, and military information (139) which we require.

Let it be remembered that it is only by plotting on the ground itself that an officer will acquire the habit of sketching rapidly the features of a country. In one case only (122) may we take notes of some measurement; but even then it is not indispensable.

When the canvas has been plotted, the details are filled in by a similar process, viz., by measuring distances and angles; and it is therefore logical that we should successively determine upon the instruments destined for that purpose.

ERROR IN THE ANGLE.	SCALE—NUMBER OF INCHES TO THE MILE.	MAXIMUM LENGTH OF SIDES IN YARDS.
1' . . .	2 . . .	15126
	4 . . .	7563
	6 . . .	5042
15' . . .	2 . . .	1008
	4 . . .	504
	6 . . .	336
30' . . .	2 . . .	504
	4 . . .	252
	6 . . .	168
1° . . .	2 . . .	252
	4 . . .	126
	6 . . .	84

CHAPTER IV.

DISTANCES.

(48.) A *chain*, or a rope, 100 feet long, divided into a hundred links, together with a set of 10 arrows, is sufficient to measure every distance in a survey.

Two persons, the leader and the follower, are required to take the measure. The leader starts with the arrows in his left hand, and one end of the chain in his right, while the follower, remaining at the point of starting, directs the leader in the proper line and makes him stretch the chain. The leader then plants an arrow, and starts afresh as before, whilst the follower comes up to the first arrow. The second arrow is planted by the leader, and the first taken up by the follower; and so on. When the 10 arrows have been used, the distance measured is equal to $10 \times 100 = 1000$ feet, which are noted, and the follower returns the arrows to the leader to continue the operation.

The chain should be kept as horizontal as possible, since the measure required is that of the horizontal distance. When the ground is not level, the chain being kept horizontal, the effect of gravity will curve it a little, therefore shorten its length, and the distance measured will be too great. It is, therefore, better to put the chain flat on the ground and to reduce the distance thus found to the horizontal plane. The chain used by civil engineers, or Gunter chain, is only 22 yards long. It is very convenient where the contents of an estate are to be given in acres, because ten chains in length by one in breadth measure exactly one acre.

(49.) Pacing is generally resorted to, while filling in the details of a survey (52). The trotting of a horse might also (53) be made available.

Distances can also be measured by time, when we have previously ascertained over how many yards we walk or ride in a given time.

This is not of rare occurrence in the field. When distances are measured by pacing or riding, a correction is necessary, owing to the lengthening caused by the acclivities, and the turnings of roads: on slightly uneven ground we subtract $\frac{1}{4}$ of the distance found, and $\frac{1}{2}$ when the undulations are more important.

When the atmosphere is calm, sound travels at the rate of 1118 feet per second, therefore, a musket fired may serve to measure a distance; a watch gives the number of seconds elapsed between the instant the light is seen and that when the report is heard: that number multiplied by 1118 feet gives very approximately the distance.

If no watch is to be had, the time is obtained by counting the pulsations of an artery. A sound pulse averages from 75 to 80 in a minute.

Distances may even be guessed by observing that in clear weather the windows of a house can be counted at 4000 yards. Horses and men appear as dots at 2200 yards, a horse is clearly seen at 1200 yards, the movements of men are perceived at 800 yards, and the head is distinctly visible at 400 yards.

Several instruments, known under the name of "stadia," have been constructed for the purpose of measuring distances; but as the means explained above are amply sufficient for all military surveys, we shall not enter into their description, and we refer the students to any treatise on mathematical instruments.

(50.) The distances once measured must be drawn at the scale; we must therefore illustrate, by a few examples, how to construct one.


Let us begin with a scale of 6 inches to the mile.

Since 6 inches represent 1760 yards, 1000 yards will be represented by $\frac{6 \times 1000}{1760}$ or 3.4 inches. If, therefore, we take a line 3.4 inches long, and divide it into ten equal parts, each part will represent 100 yards; if these parts are farther subdivided into ten, each new subdivision will represent 10 yards. To construct the scale, draw in pencil three parallel lines, about $\frac{1}{12}$ of an inch apart, and mark off on the bottom line $A B = 3.4$ inches. Divide $A B$ into ten parts. This is done by drawing through A a line $A O$, making with $A B$ any angle, marking

off any length $A C$, and taking it ten times from A to C : joining $C B$, and through the points of divisions $c_0, c_1, c_2, \&c.$, drawing parallels to $C B$, these will divide $A B$ into ten equal parts. Produce $A B$ to the left,

FIG. 25.

Scale of Six Inches to One Mile.




take $A B$ equal to one part, and by the same process divide it into ten. Ink the two bottom lines; through the points of division draw perpendicular to them, limiting their lengths to the top line for the primary divisions, and the middle one for the subdivisions; number the divisions, and write on the right the unit of measure which in this case is "yard."

This scale is used on the paper, by means of a pair of compasses, as we would employ a chain or a yard. Suppose we want to take off 470 yards; place one point of the compasses on division 400, and the other point on the 7th subdivision: the length included between the two points is 470 yards. Conversely, to value a dimension of the drawing, take it with the compass, place one point on the division 0, and read the figure corresponding to the right point. If this point does not fall exactly on a division, move it to the left until the right point coincides with the nearest division, then the left point will mark the required subdivision.

FIG. 26.

Scale of Six Inches to One Mile.




Since 6 inches represent 1760 yards or 80 chains, therefore, 60 chains = $\frac{6 \times 60}{80} = 4.5$ inches. Take a length of 4.5 inches, divide it into six equal parts; and if we subdivide the left part into ten, we shall have subdivisions representing single chains.

To construct a scale of 2 inches to the mile. In this case we cannot show parts representing 10 yards each. Since 2 inches correspond to 1760 yards, 4000 yards are represented by $\frac{2 \times 4000}{1760} = 4.54$ inches. Divide this length into 4 parts (Fig. 27), they will show 1000 yards: dividing into 10 we have subdivisions of 100 yards.

FIG. 27.


Scale of Two Inches to One Mile.



(51.) To construct a scale $\frac{1}{20000}$, we find that a distance of 3000 yards is to be represented by $\frac{3000 \times 36}{20000} = 5.4$ inches (Fig. 28). Divide the length into three parts, we shall have divisions of 1000 yards, and subdivisions of 100 yards.

FIG. 28.


Scale of $\frac{1}{20000}$.



(52.) Should the distance be measured by pacing, a proper scale must be constructed. Although the length of a pace is not a constant magnitude, we may assume that in general 2000 paces make up a mile. If the plan is to be made on a scale of 4 inches to the mile, then since 4 inches represent 2000 paces, we shall have divisions of 100 paces

FIG. 29.


Scale of Four Inches to One Mile.



(Fig. 29), and subdivisions of 10 paces, in dividing these 4 inches

into twenty parts, and subdividing one part again into ten. If 2000 of our paces do not make a mile, we can ascertain how many do by walking over a distance which has been measured.

FIG. 30.
Scale of 15000.



(53.) Scales are also made for distances measured by time.


Suppose, for instance, that we employ either the pace, the trot, or the gallop of a horse, and that we want to construct a scale of $\frac{1}{15000}$. We first ascertain at what rate our horse proceeds: in general a horse goes over 100 yards walking, 180 yards at a moderate trot, 230 yards at a fast trot, and 280 yards at a gallop in one minute.

We then calculate that in walking 20 minutes the horse goes over 2000 yards, a distance represented by $\frac{2000 \times 36}{15000} = 4.8$ inches; that at a moderate trot and fast trot he goes in ten minutes over 1800 and 2300 yards respectively distances represented by $\frac{2800 \times 36}{15000} = 4.3$ and $\frac{2300 \times 36}{15000} = 5.5$ inches; and that at a gallop he makes 2800 yards in ten minutes, or 1400 in five, a distance represented by 3.3 inches. These lengths, 4.8, 4.3, 5.5, and 3.3 being respectively divided into twenty, ten, and five parts, will give us parts representing one minute.

(54.) In examining foreign plans it is found very useful to construct for them a scale in English measures. Suppose that it is a French plan, the unit of measure of which is the metre. If the representative fraction of this plan is given, we have only to proceed as in a former example (51); but if this fraction is not given, we take off on the scale any distance, say 1000 metres. Let that distance measure 3.9 inches, then we know

that 3·9 inches represent 1000 metres (Fig. 31), or $1000 \times 3\cdot28$ English feet = 3280 feet = 1093·33 yards. It is now easy to find that 1000 yards are represented by $\frac{1000 \times 3\cdot9}{1093\cdot33} = 3\cdot56$ inches, and we proceed as in former examples.

FIG. 31.



(55.) It has been said before (48) that the distances obtained from direct measurement on an inclined ground should be reduced to the horizontal plane, inasmuch as their projection only is required. For the student familiar with trigonometry, this reduction offers no difficulty, since the projection is equal to the distance measured multiplied by the cosine of the angle of inclination. As tables of sines are not always at hand, we give here the reduction ready made. (See 115.)

DISTANCE ACTUALLY MEASURED 100 YARDS.

ANGLE OF INCLINATION.	DISTANCE REDUCED.
0° 100
5 99·6195
10 98·4808
15 96·5926
20 93·9693
25 90·6308
30 86·6025
35 81·9152
40 76·6045
45 70·7107


(56.) Two points determine a direction, but when they are some-

what distant, it becomes a difficult matter to measure along that direction, unless it be properly traced or signalled. We shall therefore begin with the following problem :—

To mark on the ground the direction between two given points, A and B.

1st. If one of these points, A, is accessible, an observer takes his station at it, whilst another (Fig. 32), C, plants staves in the

FIG. 32.



direction of B, so as to make them coincide with the vertical of B, which is ascertained by A, who signals to C with the hand until the coincidence takes place.

2nd. If the direction between A and B is to be produced, we place a staff in C where the vertical of B masks that of A. (Fig. 33.)


FIG. 33.



3rd. If both points are inaccessible. (Fig. 34.)

When neither point is visible from each other, two observers, a and b, place themselves out of the direction A B, facing each other: b

FIG. 34.




makes sign to a to move until he is in the dressing b A; then a puts in a similar manner b in the position b' where he masks B: again, b' moves a to a' on the direction b' A; a' in his turn places b' to b''; and

so on. In this manner a moment arrives when both persons respectively conceal from one another's view the points A and B: when such is the case they plant staves, and proceed as before.

If both observers are too far apart to perceive each other's signs, b places himself in the direction a A; a facing b marches towards A B;

FIG. 35.




and b, by more rapid motions, keeps himself in the dressings a' A, a'' A, &c., until he conceals B from the sight of a. Then all the points A, a', b', B, are in a line, and staves are planted as before.

Although a military survey should be executed according to the principles laid down in the former chapter, yet, as we may fail to obtain proper instruments to measure angles, it is well that an officer should understand to what advantage he can turn a mere chain (or his pace), and the following examples will familiarize him with that simple instrument:—

(57.) *To trace on the ground a perpendicular to the extremity, A, of a line, A D, which cannot be produced.*

FIG. 36.




Let any point, C, be taken; chain or pace C A; trace the line C H = C A. Produce C H (56) and make C B = C H.

The line A B is the perpendicular required.

A simple process for setting off a right angle on the ground consists in making a triangle with three pieces of cord of the respective lengths

3, 4, 5, or in this proportion, placing the side 4 on the direction, A B, with which the angle is to be made, and stretching the other two until they haul together on the ends of side 4, the side 3 will give the direction at right angle with A B.


FIG. 37.



(58.) To find the distance between two points, A B, one of which, A, is inaccessible.

Produce A B to any point, C: through C trace C D in any direction, and bisect it in E with a staff; join E B and produce it to F, so


FIG. 38.



as to make $EF = EB$. Join D F and produce it to G, where E is seen to coincide in direction with A. Then $FG = AB$.

The value of A B could be found in a different manner.

FIG. 39.




Set off $B D$ at right angle with $A B$, and make it equal to 4 yards; take $D C = 1$ yard; plant a staff in C ; set off $D E$ at right angle with $D B$, and mark on it the point E at which C and A are seen in a line. Then $D E = \frac{1}{4} A B$. If the distance, $A B$, is great, instead of yards take chains.

(59.) *To make an angle equal to a given angle, B .*

On the sides of the angle B measure the distances $B A$, $B C$; trace $B C$ and measure it also. Now, if the distance $B C$ be carried on the

FIG. 40.




line with which the angle is to be made, on $M N$ for instance, and circles be described from the centres M and N with $A B$ and $A C$ respectively as radii, the circumferences meet at a point P , and angle $P M N = A B C$.

(60.) *Through a given point, C , to draw a line parallel to a given line, $A B$.*

In A plant a staff, measure the length of its shadow, $A D$, and also the lines $A B$, $B D$. Repair to C , plant there the same staff or one


FIG. 41.



of equal length, and on its shadow, $C E$, construct the triangle $C E F = A D B$. $C F$ is the parallel required,

If there is no sun, or if both points A and B are inaccessible, take any point, D, on the direction C B; measure C D, D B (58); produce A D, and on it measure D H, having to A D the same proportion as C D has to B D: C H will be parallel to A B.


FIG. 42.



(61.) *To produce a direction, A B, beyond an obstacle.*

Take any point, H, trace the line B H, and also two other directions, H C, H D, on the other side of the obstacle.

FIG. 43.




Mark any point, F, in H B, and measure H F and B F. Through F trace F M parallel (60) to A B. Measure H G and H M.

Now, if G C and M D are made the same multiple of H G and H M as B F is of F H, then C D is in the same line as A B.

When measuring along a direction A C, if an obstacle is in the way (Fig. 44), from B measure a line B E, in any direction; bisect it in G; measure G D, produce it to H, making G H = G D. The line E H is equal to B D.


FIG. 44.



(62.) *To find the distance between two inaccessible points, A and B.*


If any point, C, on the direction A B is accessible (Fig. 45), set off the perpendicular C D and take on it the distance D E, a known part. Trace M N perpendicular to C D, and on it mark the points M and N in a line with E B and E A; M N shall be the same part of A B as D E is of E C.

FIG. 45.



If there is no point accessible between A and B (Fig. 46), take any point, C. Measure the distances C A, C B (58). Take C D an exact

FIG. 46.




fraction of C A, and C E the same fraction of C B. Measure D E; it shall also be the same fraction of A B.

(63.) *To bisect an angle.*


If the vertex is accessible, from it as centre describe a circle, measure the chord $A B$, bisect it in O ; $C O$ shall bisect the angle.

FIG. 47.




If the vertex is inaccessible (Fig. 48), trace any line, $A B$. Measure the angles $C A B$ and $C B A$, take half their sum, and construct angle

FIG. 48.



$C A D$ equal to it. The middle, O , of $A D$ belongs to the line that bisects the angle C .


FIG. 49.



If the angle itself is inaccessible (Fig. 49), mark any two points, E and D, on the direction of the sides. Through D trace D G parallel to C E; measure equal distances, D G, D H; produce H G till it meet C E produced in I. Bisect H I in O: the line C O shall bisect the angle given.

(64.) *To determine the direction of the capital of a bastion or of any inaccessible work.*

FIG. 50.




Trace any line, M N, cutting in M and N the prolongations of the faces. By means of the chain (63) bisect the angles C M N, C N M, by M C', N C'. These two lines meet in C', which belongs to the capital.

(65.) *To find the height, A B, of a building.*

Plant a staff, D E; find the position of the point O, where the eye

FIG. 51.




must be placed to perceive D and B in the same line with it. Measure E O, O A, and D E. A B shall be the same multiple of D E as A O is of E O.

Many other methods may be resorted to for finding the height of a building, but the most simple consists to compare the length of its

shadow with that of a pole of known height; the ratio of the two heights is the same as that of the shadows.


FIG. 52.



(66.) *To fix on a plan the projection of a point, having on that plan the projection of two lines.*


If the point X must be on both directions (Fig. 53), it is evident that its projection is at once obtained by producing the projections of the lines till they meet.

FIG. 53.



If X is on the direction of only $A B$ (Fig. 54), produce $C D$ on the ground till H measure $H X$, and draw $h x$ at the scale on the plan.


FIG. 54.



If X is on neither direction (Fig. 55), march along $C D$ till you arrive at O on the direction $B A$. Measure $O X$ and $C X$. On the plan the triangle $o c x$ at the scale.


Trace the directions $A X$, $B X$, and measure $A B$, $A D$, $D B$, $A E$,

FIG. 58.



$E B$, and at the scale construct the triangles $a d b$, $e b a$; the intersection of the lines $a d$, $e b$, fixes the position of x .

FIGS. 59 and 60.




If an obstacle (Figs. 59 and 60) prevents from moving from A to B , measure any two triangles, $A D C$, $B F H$, and proceed as above.

If the point A itself is inaccessible, (Fig. 61), measure $B C$, produce $C X$ to any point, D , forming with C and B a proper triangle, and on the plan construct the triangle $d b c$ at the scale. On the ground,


produce B D to H on the direction X A, measure D H, and carry it on the plan on d h; h a and c d produced determine the point X.

FIG. 61.



(69.) *To find the projection of several points, A B C.* (Fig. 62.)
Measure a base, D E; from D and E as centres, and radii D K, L E,

FIG. 62.



describe two circumferences; measure the chords K F, K G, K H and L M, L N, L P. On the plan draw the base at the scale on d e; describe the circumferences with radii d k, l e; and by means of the radii k f, k g, k h, l m, l n, l p, complete the triangles d h k, d g k, d f k, e l p, e l m, e l n. The other sides produced determine the projections a, b, c.

(70.) A great number of instruments have been constructed to measure angles, but some are difficult to adjust and cumbersome to carry ; we shall therefore confine ourselves to those which an officer can easily

carry with him in the field, or even construct himself in an emergency. We shall successively learn the use of the prismatic compass and the plane-table; and when they are thoroughly understood we shall readily employ any other, since the problems of topography are but few. Simplicity is the first condition which the instruments of a soldier should fulfil: theodolites, circumferentors, &c., are no doubt most valuable instruments in the hands of the engineer who surveys at leisure in time of peace, but for the field they are most decidedly unfit; the more numerous the adjustments, screws, glasses, &c., the more numerous the causes of error, and also the more subject the instrument is to be put out of order. However, as the box-sextant and the cross-staff are very portable, we shall conclude what we have to say on the measurement of angles by a few words on those two instruments.

CHAPTER V.


PRISMATIC COMPASS.

(71.) The *prismatic compass* is founded upon the property of the magnetic needle to constantly point to the magnetic pole, when horizontally supported on a pivot so as to turn freely.

The angle formed by a line and the magnetic meridian is called the *magnetic azimuth* of that line, and the value of this angle is called a *bearing*.

The prismatic compass is employed to take bearings, and therefore to measure the angle formed by two directions, since their angle is equal

FIG. 63.




to the difference of their azimuths. The angle $B A C$, for instance, is equal to azimuth $B A N$ —azimuth $C A N$.

(72.) In its most general form this instrument consists of a compass card C (Fig. 64), divided into half degrees from 0° to 360° , and fixed on a magnetic needle, which is supported on an agate centre, round which it turns freely. A sight-vane, S , is provided with a thread stretched along its opening; and a narrow slit, cut through the prism P , serves as the eye-sight. Both the sight-vane and the prism are mounted on a hinge-

joint, so as to be turned down flat, to permit putting the instrument in a case when not in use.

FIG. 64.



The prism can be raised or lowered in a socket, to facilitate the reading of the graduations of the card as they pass in succession before it.

A little spring, usually under the sight-vane, serves to check the vibrations of the card, when taking bearings.

To take the bearing of a direction *A B*, station at *A*, turn the prism and sight-vane up, as in the last diagram, raising or lowering the prism until the divisions of the card become distinctly visible, and hold the instrument horizontal, either in the hand or on a stand. Turn it round until the object *B* is seen through the slit in coincidence with the thread of the vane; check then the vibrations of the card by pressing on the spring, and the graduation of the limb that is seen to correspond to the thread gives the required bearing or magnetic azimuth of line *A B*.

Dark glasses are sometimes added to the prism to take azimuths of the sun, and a mirror is also found sliding along the sight-vane to reflect the image of objects much above or below the level of the eye; but they are useless for military purposes.


(78.) The angles measured with the prismatic compass are obtained reduced to the horizon, and this advantage, together with the portability and simplicity of the machine, renders it essentially fit for officers in the field. It is almost exclusively employed to fill in the details of extensive surveys, and also to make the triangulation of military sketches.

(74.) In order to protract the bearings several parallel lines are previously drawn across the minute, more or less close, according as the details are more or less numerous. They represent the directions of the magnetic meridians, which can be considered sensibly parallel in ordinary

surveys. An advantageous contrivance consists in drawing them at intervals equal to the divisions of the scale employed. Thus at the scale of 4 inches to a mile, if we make those intervals alternately equal to the $\frac{1}{4}$ and the $\frac{1}{2}$ of an inch, they will represent 110 and 55 yards, and serve in filling in the details.

(75.) The protractor consists of a semicircle of thin transparent horn. Its circumference is subdivided into degrees and half degrees, and its graduations on the outer arc extend from right to left from 0° to 180° , whilst on the inner arc, corresponding to the rest of the cir-


FIG. 65.



cumference, the graduations from right to left run from 180° to 360° . The margin A·B is parallel to the diameter 0—180.

There is another kind of protractor, formed of a rectangular piece of

FIG. 66.




ivory, divided and graduated from left to right, as in this diagram, the margin A·B coinciding with the diameter 0—180. Its surface is covered with a series of parallel lines perpendicular to the margin.

In protracting the bearings it should be carefully borne in mind that they are counted from north to east, south and west.

If we want, for instance, to protract a bearing of 50° taken at C, place radius 50° of the horn protractor on one of the parallel lines, and slide it along until the margin passes through C, then draw C B.


FIG. 67.



From 0 to 180° , the graduations of the outer circle serve to protract, but from 180° to 360° we have recourse to the inner circle.


When employing an ivory rectangular protractor, these parallel lines will represent perpendiculars to the magnetic meridian, and correspond to those that are drawn across the instrument. To protract with it a

FIG. 68.



bearing of 60° , for instance, through c , place the centre of the protractor at c , and make any one of the lines across it coincide with one of those drawn on the paper, without moving the centre from c . The


FIG. 69.



margin $A B$ coincides then with the magnetic meridian. At the extremity of radius 60° make a dot with the pencil, and the line drawn from c to that dot will bear 60° with the magnetic meridian. If the bearing is greater than 180° , the protractor is placed to the left of the point c , and the graduation of the inner circle serves to protract the angle as before.

Although the ivory protractor is most generally employed in this country, preference should be given to the horn one, as giving more exactitude: it will, in fact, be readily understood that the slightest deviation from coincidence between the short line across the ivory instru-

FIG. 70.




ment and that of the plan, will, owing to that shortness, much affect the true position of the margin. The same deviation with the horn instrument, whose radii are all equal, will not produce so great an inexactitude.

The following problems will familiarize with the use of the prismatic compass:—

(76.) 1st. *To find the projection of a point, X, knowing those, a, b, of two given points, A and B.*

FIG. 71.




Station at A, take the bearing of A X; repair to B, take the bearing of B X; protract those angles through a and b, the projection x is found.

This problem enables us to fix on the plan the station we occupy on the ground we survey.

If A and B are inaccessible and X accessible, station at this point, take the bearings of X A and X B, protract them through a and b as before, and produce a x and b x till they meet in x.

This method of intersection is very expeditious, since several azimuths can be obtained at the same station (Fig. 72). The angles

FIG. 72.



z, y, x, &c., should not be too acute (44), and when we find them to be so, we must verify the position of those points by taking a third bearing from another station, from c, for instance.

(77.) 2nd. *To survey a road A B C D.*

Station at A, take the bearing of B, protract it through a: measure A B and carry it on a b at the scale. At B take the bearing of C and protract it (Fig. 73), measure B C, draw it on b c, and so on. This method, known under the name of *traversing*, can be simplified by omitting every other station, B, D, &c. Having taken and protracted the bearing of B, we measure A B, and without stationing at B we go

FIG. 73.





FIG. 74.



on and measure B C. Arrived at C, we mark the distance a b at the scale, and take the bearings C B and C D, which we protract, and having carried distance B C on b c, we start afresh. This expeditious process is called taking the back angle.


If some points of importance, H, M, N (Fig. 74), lie on either side of the road, their bearings, taken from A, B, C, D, enable us to determine their projections on the plan.

3rd. *To trace the direction of the capital of a bastion or of an inaccessible work.* (Fig. 75.)

Mark two points, a, b, on the direction of the prolongation of the

faces; take the azimuth α of a A , that β of b B , and their difference $\alpha - \beta = \text{angle } A C B$, and $\frac{\alpha - \beta}{2}$ is the angle formed by the capital and either face.

FIG. 75.



(78.) This instrument is preferable to the plane table in mountainous or woody countries where several points cannot be seen from a same station. *It is the best instrument for military purposes.*

In using the instrument, it is advisable to place it on a stand, because while holding it in the hand the slightest motion of the body precludes accurate reading, and also because it becomes easier to place the sight vertical, a most important condition, inasmuch as its obliquity may cause errors of even 10 degrees in the azimuth of an object much above the horizon. We should also carefully avoid the vicinity of any steel scabbard, sword, bayonet, and even carry no knife or key in our pocket, for they would affect the direction of the needle.

(79.) The magnetic and terrestrial meridians do not coincide; the angle they form at a given point is called the declination or variation. It can be found by tracing a terrestrial meridian and comparing its direction with that of the needle. Conversely, by means of the declination, the true meridian can be obtained.


This declination varies in different parts of the globe; but a prismatic compass constructed for England may be employed anywhere, since the angles it determines, being the difference of two azimuths, are

not altered where both bearings are simultaneously larger or less by the same quantity. The survey will therefore proceed equally well ; but we shall require the declination to trace the direction of the true meridian.

The variation, for the same locality, is subject to periodical changes ; thus, in 1580, it was $11^{\circ} 30'$ east at Paris ; it was 0 in 1663, and $19^{\circ} 26'$ west in 1861. Besides those local and periodical changes in the declination, the needle presents diurnal variations which may amount to as much as 25 minutes : they will of course affect more or less the exactitude of the survey ; but as the prismatic compass serves only to fill in the details in regular surveys, the error can be neglected.

(80.) A French officer, M. Trinquier, has lately invented an instrument, *echelle-rapporteur*, which is admirably suited for field purposes, inasmuch as it permits to protract bearings and lay down distances without protractor rule, scale, or compasses. The principle is so simple that one may be constructed in a few minutes. It consists of a board,

FIG. 76.



A B C D, on the middle of which is fixed a circle of thin pasteboard movable in every direction round its centre, E. Its circumference is divided into 360° , and its surface is ruled over by two systems of parallel lines at right angles to one another.

The lines parallel to diameter 90° — 270° are red, and are at intervals more or less great, according to the scale of the intended sketch, each interval representing 10, 20, &c. paces. Every fifth line is made

thicker to facilitate the reading. The other set of parallels is black, and the lines are at any interval deemed convenient.

An index is invariably fixed on the board at G; it touches the graduated circle, but does not prevent it from turning. The diameter G E will represent the magnetic meridian.

The paper on which the sketch is to be made must be thin or transparent; it is stretched over the board, and is kept in its place by four drawing-pins, p, p, p, p. The board is cut out on one side to allow the fingers to turn the circle.

To trace a direction, the bearing of which is found to be, say 130° , we turn the circle until graduation 130° comes under the index G: it is clear that all the black lines are now parallel to the direction required, and this is at once traced by following with a pencil the black line seen through the paper. The distance measured in that direction—say 150 paces, is laid down by marking over the black line across 15 intervals of the red lines.

The instrument may be made still more handy in fixing the prismatic compass in a corner of the board by means of two brass screws.


CHAPTER VI.

PLANE TABLE.

(81.) The *plane table* is employed to draw the angles at the same time they are observed, instead of measuring them and protracting them afterwards.

In its most complete state it consists of a square board of wood about a foot or eighteen inches square, mounted on a tripod stand; it can move freely on that tripod, and be placed in any position in which a clamp screw permits to fix it. The paper is stretched and fixed

FIG. 77.




upon this board. The angles are observed by means of a brass rule supporting a telescope movable in a vertical plane round the point of support.

This instrument was hitherto much complicated by a quantity of

contrivances destined to render it more perfect, but in reality adding to the causes of error; it is at present very seldom employed in this country by civil engineers, or officers. For military purposes, however, it is unquestionably a most valuable instrument, which saves both time and trouble; and its construction can be so simplified as to enable almost everyone to attempt it.

The staff officer in France frequently carries his plane table in his holsters: it is formed of 6 thin rules, about 2 inches wide and 1 foot long, pasted on a piece of linen or kid, on which the paper is fixed. These rules are parallel and a little apart, so as to be easily folded flat together. Two other rules, A and B, maintain them open and give

FIG. 78.



strength to the whole; they turn on a pivot at one end, and a hook at their other extremity catches a ring screwed to the splits 1 and 6. A movable socket under the rules 3 and 4 permits to fix this table on a stick when it is required for use. After work, the stick is removed, the socket unscrewed, the hooks unfastened, the rules A and B turned round their pivot till they coincide with splits 1 and 6, and the various pieces folded alternately one upon another. (See 90.)

The telescope, or sight ruler, is replaced by a wooden ruler with two needles fixed in an upright position.


FIG. 79.



A plane table may also be formed with a piece of pasteboard provided with a socket of strong paper, into which a stick may be inserted for support. The sight, reduced to its most simple form, will be the edge of a piece of paper folded longitudinally.

The sketch book on the left arm might even be a substitute for the table.

FIG. 80.




(82.) Whatever the form of a plane table may be, we use it for fixing on the minute the projection of the vertex of a triangle, a side of which is given, or two vertices of a quadrilateral figure knowing the other two, or the fourth vertex knowing the other three. In all these problems, the angles are traced instead of being measured.

(83.) 1st. *To fix on the plan the projection of a point, X, having already those, a, b, of two accessible points, A and B.*

Station at A placing the table as level as possible by moving its

FIG. 81.



legs ; place the sight ruler on a b, and turn the table till the point B is seen in a line with the edge of the ruler ; then the line a b has been placed in a same vertical plane with A B, and the table is clamped firm


in that position. Keeping the edge of the ruler on the point a , turn it till it is in a line with X and draw $a x$.

Repair to station B and repeat the same operations: place the ruler along $a b$, turn the table till A be in a line with it; clamp the screw, turn the ruler round b till x be in a line with it, and draw $b x$.

The intersection of $a x$ and $b x$ determines the projection x of the point X and the angles $B A X$, $A B X$ have been traced and at once reduced to the horizon.


In an open country several points, x, y, z, t , may thus be determined by one station only at each extremity of the given line, $A B$. (Fig. 82.)

FIG. 82.



(84.) 2nd. *One of the two given points, B , is inaccessible.*

FIG. 83.




Station at A, and draw a x as above. Station at X, place the ruler along a x , turn the table and clamp it as soon as A is in line; place the ruler's edge on b, and turn it round till B is seen, trace a b, which intersects a x , at the required point x .

(85.) 3rd. *The two given points are inaccessible, but a station can be made between them.*

Station at a point C situated on direction A B, and on the plan

FIG. 84.



(Fig. 84) mark in c , its *supposed* projection. Place the ruler on a b, and turn the table till A (or B) be in line, and clamp it. Place the ruler on c , and make it move round it till X be in line, and draw c,x , giving angle $x,c,b = XCB$; plant a staff or leave a man on C.

Repair to X, place the ruler on x,c , turn the table till C be in line, and clamp it; put the ruler on b and move it round till B is in line, and draw b,x ; put the ruler on a and turn it till A is in line, draw a x , which intersects b,x at the required point.


(86.) 4th. *To fix the projections of two accessible points, X and Z, by means of two inaccessible given points, A a, B b.* (Fig. 85.)

On a corner of the minute, or on a piece of paper provisionally stuck on it, draw a line x,z , which we suppose to represent X Z. Station at X, and place x,z in the same vertical plan with X Z (84), and clamp the table: put the ruler on X, and turn it till A is seen in line, and draw x,a ; turn again till B is in line, and draw x,b . Repair to Z, and by a similar operation draw z,a , z,b .

A quadrilateral figure, x,z,a,b , is thus formed, similar to A B X Z.

To fix it at the scale on the minute, on a, b , take $b, o = a, b$, and draw $o p$ parallel to a, z , and $o q$ parallel to z, x ; the figure $b, o p q$ represents the quadrilateral figure $A B X Z$ at the scale. It is then easy to draw it on a, b : from a as centre with radii $o p, o q$ describe two

FIG. 85.



circumferences; from b as centre with radii b, p, b, q , describe two other circumferences, which shall meet the former in x and z , the required projections.

To draw through a given point a line parallel to a given line, place the sight ruler on the line and look for some object 200 or 300 yards distant in that direction: move the ruler to the given point and turn it round till the same object be in line the edge of the rule will be parallel, or very nearly so, to the given line.


The parallels $o p, o q$, are usually drawn in that manner.

5th. *Three inaccessible points, A, B, C (a, b, c), being given, to determine the projection of a fourth point, X , accessible.*

The point X is at the same time on the segment of circle described on $A B$ and containing the angle $A X B$, and on the segment containing angle $B X C$ described on $B C$. If, therefore, we station at (Fig. 86) X , and construct the angles $A X B$ and $B X C$, which is easily done by assuming any point, x , for vertex on an auxiliary piece of paper, and aiming with the ruler successively at a, b , and c , and tracing $X A$,

$x, b, x, c,$ the projection X will be determined on the plan by describing

FIG. 86.



on a, b a segment that contains angle $a, x, b,$ and on b, c a segment containing angle $b, x, c.$

This process is not very practical. Among several other methods the best consists in fixing on a corner of the table a piece of tracing-paper. Taking on it any point, x , at random we draw as above the lines $x, a, x, b, x, c,$ making the angles $A, X, B, B, X, C.$

Unfastening the tracing-paper, we move it on the minute till these three lines pass respectively through $a, b, c,$ and then we prick x , and obtain the required projection.

This problem enables us to find our place, x , in a survey by means of three given points.


The plane table is an excellent instrument in even and open ground, where a canvas is rapidly constructed; and those officers who have once employed it will always prefer it to any other; nevertheless, it should be rejected in mountainous or woody countries, where several points can seldom be seen from the same station.

(89.) A magnetic needle or compass may be advantageously added to the plane table for the purpose of facilitating the finding of a station. When the projection a, b of a line, A, B , has been placed in the same vertical plane with A, B (84), read the angle marked by the needle, and whenever it is required to place the table in a position parallel to this, it is done by turning it till the compass gives the same reading.

By means of this addition the plane table permits to operate with


great rapidity. Let us suppose, for instance, that in the course of a survey it is required to fix the projection of an accessible point, X,

FIG. 87.



knowing those, *a*, *b*, of two points, *A*, *B*, in other words, to find our place in a survey (76), having already fixed *a*, *b*, on the minute. Stationing at *x*, turn the table till the compass gives the reading alluded to: clamp the table, place the ruler on *a*, and turn it till *A* is seen; draw *a x*: place then the ruler on *b*, turn it until *B* is seen, and tracing *b x* it will intersect *a x* at the point *x* of station. If a compass cannot be procured, we may fix a pin or a needle on the plane table, and with the help of a watch construct its shadow during the different hours of the day. The sun-dial resulting therefrom will serve for the few following days; and to place the table in a direction parallel to that of departure, it will be sufficient to turn it until the shadow corresponds to the hour at which we require this parallelism.


FIG. 88.



(90.) A plane table was lately constructed by Major Fèvre, of the

French Staff-Corps, for military reconnaissance. It is 11 inches long, 8 inches wide, and weighs only 28 ounces. The sides are surrounded by a brass tube, A, destined to receive a bolt, B, which carries with itself all round the table both the magnetic compass and the sight ruler. This bolt is introduced into the tube by means of a slit, C, closed by a spring, and a screw, D, permits to clamp the ruler and compass whenever necessary. The sight ruler is made of wood, and when not in use its brass pins can be buried in grooves cut through it. Under the table we find a hollow handle of wood, E, movable round a spherical joint, F, so that the table may be held in the left hand whilst on horse-back, or fixed to a stick when on foot.

FIG. 89.




The paper is fixed to the table by means of four grapples, and rendered tight by screws protruding underneath.

When the instrument is not in use, the sight ruler, the magnetic compass, and a plummet of wood can be placed in hollows, scooped out in the under surface of the table, and the whole may be carried by a string attached to the handle.

The magnetic compass is of a peculiar description; the bottom of the box is movable and bears two diameters at right angles, each letter, N, S, W, E, corresponding to a side of the table. When at the beginning of a survey the azimuth of a direction is taken, the extremity,


S, for instance, is brought under the point of the needle. The compass being afterwards moved to one of the adjacent sides of the table, the needle will point to W, N, or E, as the case may be, thereby avoiding the necessity of adding 90° to the azimuth whenever the compass changes side.

FIG. 90.



(91.) Major Fèvre combines the scale and compasses into one instrument. It consists of two rules of equal length, the wider one carrying any

FIG. 91.



two scales, say four inches and two inches to the mile. These two rules can slide upon one another, so that at both extremities the distances, a b , are equal. Two steel points, s s , fixed at the end of each ruler, will thus enable us to measure or carry a distance, the reading of which is found at the extremity, E , of the small rule. A scale of paces may also be made on the bottom of the groove of the wider rule.

This plane table working excellently in the field, is now superseding all others.

CHAPTER VII.


SEXTANT AND CROSS-STAFF.

(92.) The *box sextant* is employed to measure the angle between two objects. It consists of a cylindrical box containing an index-mirror, under A, to which is attached on the upper surface or plane of the sextant an index-arm, E. Both this mirror and the index are movable by means of a screw, B. The index-arm is terminated by a vernier wherewith we read the graduations of the limb, m n, within a minute (95). The graduation extends from 0° to 120° ; and a magnifying glass, M, facilitates the reading.

The sight D, to which a telescope may be adjusted if required, is opposite to another mirror (under G), called the horizon-glass, that has half its surface silvered.

Both mirrors are fixed, by the maker, perpendicularly to the

FIG. 92.



plane of the sextant. By means of two levers in H the observer interposes two dark glasses between the mirrors and an object too brilliant to be easily seen, and the eye-piece of the telescope is also

provided with a dark glass for the same purpose. It is often recommended to adjust this instrument before employing it, but we should advise officers to meddle as little as possible with adjustments: if the sextant is put out of order, it is better to send it to the optician; yet, as accidents will happen in the field, and opticians are not always at hand, here is an account of the process.

(93.) To be in perfect adjustment, both the index-mirror and the horizon-glass should be perpendicular to the plane of the sextant, and both parallel when the vernier is at 0.

Through the process of construction of the maker, the index-mirror is supposed to be right, therefore we have only to ascertain the perpendicularity of the horizon-glass. To do so, hold the sextant horizontally and look through the sight D, at the distant horizon or at the sun. If two images appear, unscrew the key C, and putting it to the key-hole G, turn it till the two horizons or the two suns coincide. The glass is then right.

To verify the parallelism, place the index exactly at 0, and, holding the instrument horizontal, look to the angle of a house far distant or to the lower limb of the sun—so placing the eye as to see directly through the hole of the slide and the unsilvered part of the horizon-glass. The direct image and that reflected by the index-mirror to the horizon-glass should appear as one: if not, fit the key C to the key-hole I, and turn till both images coincide. The instrument is then adjusted.


(94.) To measure the angle between two objects, set the vernier at 0° , hold the instrument with the left hand in the plane of the objects, look through the slide D or the telescope at the left-hand object, and with the right hand turn the screw A until the reflected image of the right-hand object coincides with the direct image of the left. The vernier marks then the angle required.

To obtain the angle subtended by two objects situated in the same vertical plane, set the vernier at 0, hold the instrument vertically in the right hand, and bring the reflected image of the upper object to coincidence with the direct image of the lower one. The vernier marks then the required angle.

(95.) The *vernier* is a contrivance applied to an instrument employed for the measurement of angles or distances, so that the fraction of the

smallest division of a graduated limb or scale may be read. It consists of a little arc or rule according as the graduated scale is a circumference or a straight line.

FIG. 93.



Let us take on the limb and on the vernier two equal lengths or arcs, the first containing $n-1$ divisions equal to D , the second n divisions equal to d . These lengths will therefore be represented by $(n-1) D$ and $n d$, and as they are equal $(n-1) D = n d$, hence $D - d = \frac{D}{n}$. It follows from this that when the 0 of the vernier has passed a division of the limb, this 0 is in advance upon it of $\frac{D}{n}$, $\frac{2 D}{n}$, $\frac{3 D}{n}$, &c., according as the first, second, third, &c., of its own divisions coincides with one of the limb's divisions. Hence, when measuring distances or angles with an instrument provided with a vernier, we must ascertain which division of the vernier coincides, multiply it by $\frac{D}{n}$, and add this product to the last division of the limb over which the 0 of the vernier has passed. In the box sextant the value of $D = 30$ minutes, and $n = 30$, therefore $D - d = 1'$. The limb is divided in half-degrees, and 30 divisions of the vernier correspond to 29 of the limb. If the 0 of the vernier (marked with an arrow) has passed the 12th degree of the limb, for instance, and if its 9th division coincides, the angle measured is $12^\circ - 9'$. If the arrow has passed $43^\circ 30'$ and the 23rd division of the vernier coincides, the angle $= 43^\circ 53'$.


(96.) The box sextant *seems* preferable to the compass when accuracy of measure is requisite, since it can, even without employing a stand, give an angle accurately within one minute, and measure the angles of elevation and depression besides. It has, however, the drawback of

furnishing us with the actual angle instead of its horizontal projection, and a complete series of angles round a station may considerably exceed or fall short of 360° . The error due to this cause exceeds that of the prismatic compass used with a stand, and the exactitude of measurement is, after all, but apparent, therefore the sextant cannot be preferred to the compass.

There is a mode of reducing angles to the horizon, but it is tedious, and should be avoided: a little practice will enable the observer to do it himself by selecting a point exactly vertical above or below the objects, in the plane of the true horizon.


(97.) In order to understand upon what principle the sextant is constructed, let it be observed that if a ray of light, $O R$, falls obliquely upon a mirror, $A B$, it is reflected in a direction, $R I$, making with

FIG. 94.



the perpendicular, $V R$, the angle of reflection, $I R V$, equal to the angle of incidence, $O R V$. Now, when two mirrors, $A B$, $A C$, form between themselves an angle, a , if a ray of light, $O R$, falls


FIG. 95.



upon one of them, $A C$, to be reflected to the other, $A B$, in $R R'$, and there again reflected in the direction $R' I$, the angle formed by the direct ray, $O I$, and its reflected image, $R' I$, is double the angle a . This is seen at once on the figure: Angle $R' I O = R R' I$


+R' R I=180-2 r'+180-2 r=360-2 (r+r'). But in triangle A R R', a=180-(r+r'), therefore R' I O=2 a.

FIG. 96.



Let A be a mirror (Fig. 97), B another one with half its surface silvered, and M P two objects subtending an angle, M E P. The image of M is reflected from A to B, and from B to E, and the angle

FIG. 97.



A E B is, according to what has just been said, equal to twice the angle o A G of the mirrors. Now, if P is in a line with E B, the angle A E B is precisely the angle required.

In the box sextant the mirror A constitutes the index-mirror, and B the horizon-glass. As the latter is unsilvered in *bb*, the object P is perceived directly along *EP*; therefore, if the mirror A is turned until the reflected image of M coincides with P, the two mirrors will then make an angle equal to half that subtended by the objects. In the box sextant, the index-arm A G, fixed to mirror A, points to the graduation of the limb L O, which is numbered double, so as to give


the real angle at once. When the movable mirror, A, is parallel to B, the index points to 0.

(98.) The problems which we have investigated with the plane table and the prismatic compass can be solved by means of the sextant, by measuring and protracting the angles instead of tracing them, as with the table, and plotting them by differences of azimuths, as with a compass. We shall not, therefore, repeat their solution, as the student, having once understood how to handle the sextant, can easily find it. One application or two, however, may be given.

1st. *Through a given point, A, to trace on the ground a line perpendicular to a given line, B C.*

If A is without B C, plant a staff at it, set the vernier at 90° , and marching from C to B, look through the slide towards B till

FIG. 98.



the reflected image of the staff coincides with B. The point D, at which the coincidence takes place, determines A D, at right angles with B C. If A is on B C, set the vernier at 90° , and send a man with a staff to the right, while you stand at A and look through the


FIG. 99.



slide at C (Fig. 99). As soon as the reflected image of the man coincides with C stop him, and the point D, which he then occupies, determines A D perpendicular to B C. When the man is sent on the left the sextant must be inverted.

2nd. To find the distance between A accessible and C inaccessible.

FIG. 100.




Set the vernier at 90° , and through A trace a perpendicular, A B to C A, as explained; then set the vernier at 45° , and marching in direction B A, and aiming at A, move backwards or forwards until the reflected image of C coincides with A. The point B, at which it happens, gives us the isosceles triangle C A B, and $BA = AC$.

(99.) By means of the *cross-staff*, an instrument very familiar to Civil surveyors, perpendiculars on the ground are traced; it can advantageously be employed in military surveys to fill in the details.

It has various forms, The most general consist of a cylinder or a


FIGS. 101 and 102



prism of brass, having four longitudinal grooves, cut through so as to give two directions, at right angles.

It is sometimes formed of a circle of brass with two diameters at right angles bearing a sight at each extremity.


FIG. 103.



In whatever form, it is fixed upon a stand so pointed at its extremity as to be easily driven and steadied into the ground.

As it very seldom happens that this instrument is to be found in the field, it can easily be replaced by a small board nailed to a stick. Four needles or pins planted at right angles, as in the diagram, will


FIG. 104.



answer the same purpose as the grooves. This instrument will be found very handy in mountainous and woody districts, ravines and marshes; and when measures are taken by pacing, the details of a survey may be rapidly filled in by its assistance, as may be seen by the following few exercises.

(100.) 1st. *Through a given point, A, to trace a perpendicular to a given line, B C.*

FIG. 105.




March along B C, carrying the instrument with the left hand, and aiming along that direction through a groove, and see through the other if you can perceive the point A, if not, march on. After a few trials the point A will be seen; then the point P, from which A is seen through the second groove, gives the extremity of the perpendicular required.

(101.) 2nd. *To produce a line beyond an obstacle.*

Let $A B$ be the line; at B trace $B C$, perpendicular to $A B$, which


FIG. 106.



is done by looking through a groove along $B A$, and sending a marker to plant a pole in the exact direction of the rectangular groove; measure $B C$, trace $C D$ perpendicular to $B C$, and produce it till the obstacle is passed; trace $D E$ perpendicular to $D C$, making it equal to $C B$; then $E F$ traced at right angle with $E D$ will be in the prolongation of $A B$.

(102.) 3rd. *Through a given point, A , to draw a line parallel to a given line, $B C$.*


FIG. 107.



Find on $C B$ the foot of the perpendicular $A D$. Place the cross-staff in A , one sight directed on $A D$, the other will be directed on $A H$ parallel to $B C$.

(103.) 4th. *To find the distance between two points, A, B , one of which, A , is inaccessible.*

FIG. 108.




In B trace a line, $B C$, perpendicular to $B A$, and mark its middle, D ; at C trace $C E$ at right angle with $C B$, and march along it till

arrived in E you perceive D and A in a line, the length C E measures then A B.

(104.) 5th. *To find the distance between two inaccessible points, A and B.*

FIG. 109.




Trace any direction, C D, and mark on it the extremities C and D of the perpendiculars A C, B D, respectively drawn from A and B to that line; produce them on C G, D H. Bisect C D in E. March along D H till you see E and A in the same direction, and mark the point H from which you perceive the coincidence.

Do the same operation on C G, till in G you see E and B coinciding in direction. The line G H measures A B.

(105.) 6th. *To survey a polygon, A B C D E.*

Trace the diagonal A B: find in it the feet of the perpendiculars


FIG. 110.



p C, p' E, p'' D. Measuring the distances A p, p p', p' p'', p'' B, and the perpendiculars p C, p' E, p'' D, the figure can at once be drawn.

The sinuosities of a river, a wood, a piece of water, &c., can be obtained with great exactitude by this process:—Advancing along a


FIG. 111.



line, A B, measuring successively the distances A m, m m', &c., and their perpendicular offsets, A n, m m', m' n, &c.

(106.) The area of a field can also be found with the help of a cross-staff. To do this, trace a rectangle, A B C D, that encloses the

FIG. 112.




field. Draw it at the scale on a piece of thick paper; march along the sides of the rectangle, taking the offsets as before described, and draw the borders of the field. Calculate the area of the rectangle: cut it and weigh it: cut out the field and weigh it. Its area has to that of the rectangle the same proportion as is given by the weights.

CHAPTER VIII.

LEVELLING.

(107.) To level is to find the difference of level between two or more points. Let A and B represent two points fixed on the plan by one of the foregoing methods. In the triangle A B H, the angle H is right,

FIG. 113.



the projection A H is known by measuring it at the scale; therefore, if we could observe the angle of elevation B A H, we could obtain the altitude B H by either calculating or constructing the triangle A B H.


Again, if H B was directly or indirectly measured the problem would be solved.

The instruments of levelling are of two kinds: some give us the angle of elevation or of depression, others the height itself.

The only instruments that can be recommended to an officer for the purpose of observing these angles, are the box sextant already described, and the clinometer.

(108.) The clinometer consists of a quadrant of pasteboard or of


FIG. 114.



brass, having a plummet, A H, suspended at its centre, and graduated as in the diagram on both sides. When we require an angle of eleva-

tion A B H, we look along the edge A C, till B be in sight, when the plummet indicates the angle O C V. For an angle of depression reverse the instrument.


FIG. 115.



The clinometer is quite sufficient for every military purpose, and its extreme simplicity renders it preferable to the box sextant. At all events it makes a capital substitute for it in case of accident.


(109.) If a sextant is used (94) in the mode described, the angle A H B which it gives will not differ much from the true angle of

FIG. 116.



elevation A O B when the distance H B is great, and if the operator lies or stoops on the ground this angle will be sufficiently exact.

FIG. 117.




Where a great accuracy is necessary, a reflecting surface should be procured to give a horizontal plane. A hollow vessel, filled with a few inches of water or mercury, will at once procure this artificial horizon ;

a looking-glass might also be placed level. Whatever be this auxiliary surface, we measure with the sextant the angle $B O B'$ formed by an object B , and its reflected image C seen on direction B' . This angle is double the elevation required, since $M O B = C O N$ (97), and $C O N = M O B'$.

(110.) The distance $A B$ and the angle $B A C$ being known, the height $B C$ can be found by the formula $H = B \tan \alpha$, in which B

FIG. 118.



represents the horizontal distance, α the angle of elevation and H the altitude.

TABLE SHOWING THE HEIGHT WHEN THE HORIZONTAL
DISTANCE $A B = 100$.


ANGLE.	HEIGHT.	ANGLE.	HEIGHT.	ANGLE.	HEIGHT.
1°	1.74	16°	28.67	31°	60.07
2	3.49	17	30.57	32	62.49
3	5.24	18	32.49	33	64.94
4	6.99	19	34.43	34	67.45
5	8.75	20	36.40	35	70.02
6	10.51	21	38.39	36	72.65
7	12.28	22	40.40	37	75.35
8	14.05	23	42.45	38	78.12
9	15.84	24	44.52	39	80.98
10	17.63	25	46.63	40	83.91
11	19.44	26	48.77	41	86.93
12	21.26	27	50.95	42	90.04
13	23.09	28	53.17	43	93.25
14	24.93	29	55.43	44	96.57
15	26.79	30	57.73	45	100

An example will show how to use this table. The distance between two points is 457 yards—the angle of elevation 10° .

In the column of angles we find that for 10° there is a difference of level of 17.63, when the base is 100 yards; therefore, $100 : 457 :: 17.63 : \text{to the height required} = 80.55 \text{ yards}$.

If the student is not acquainted with Trigonometry, or if there is no table of tangents to be had, a scale of height may be constructed in the following manner:—O H representing the horizon, draw through O several lines inclined at 5° to one another. If, then, the hori-


FIG. 119.



zontal distance is carried on O H at the scale—in O C, for instance—the perpendicular erected at C will, by its intersection at D with the line corresponding to the angle of elevation observed, give the altitude C D, the length of which is found by the scale. This altitude is added or subtracted, according, as we have observed an angle of elevation or of depression: the height above the ground of the instrument with which those angles have been measured must also be added or subtracted.

(111.) There are many instruments for levelling; the only one employed to measure directly the altitudes which we shall mention, is

FIG. 120.




the French water-level, because it is easily constructed. It consists of a hollow tube, a b, of tin or brass about 3 feet long, with two empty cylinders, a d b c, soldered at its extremities, and terminated by two glass bottles. A socket, s, is inserted in a tripod. Its use is to give a horizontal direction: to that effect it is placed level at sight, and water is poured into the tube until it reaches about $\frac{2}{3}$ of the height

of the phials. The surface of the water in these bottles determines a horizontal direction, HH' .

To find the difference of level between two points, A and B, station between them: send a man to set a levelling-staff at B; look

FIG. 121.




along the surface, HH' , and read the height, BC ; send the same or another staff at D, and in the same manner obtain the height, AD . The difference of level is given by $AD - BC$.

There are several sorts of levelling-staves more or less ingenious, but if none is to be had, a pole divided into feet and inches will answer the purpose. The pole bearer, when in station, will move up and down the pole a piece of white paper, to enable the observer to see more easily its intersection with the artificial horizon. In case the latter should be too far to read the graduation, when sign is made to stop, he will himself read the figure and give it.

When the ground is very uneven, several stations are necessary;

FIG. 122.




in this case we station between $s\ s', s's'', \&c.$; and if m, m', m'' represent the back measures, n, n', n'' the measures in front, the difference of level is found by $(m + m' + m'' + \dots) - (n + n' + n'' + \dots)$. In this case a field-book will be necessary to write down these observations, whenever the distances are great.

This level is usefully employed to make a profile of the ground on any given direction, an operation occasionally required in the field for projects of fortification. We proceed along this direction, as we have just now explained, assuming any altitude for the point of departure when it is not exactly known.

(112.) A water-level may even fail us: then it can always be replaced by a little ruler, a b, suspended by two strings, c a, c b, having a little weight under it to prevent the wind from shaking it.


FIG. 123.



When held by the string, the line a b will give a horizontal direction. To make use of it for levelling along A B: Start from A, hold the ruler up to the eye, and aiming along its edge, notice to what point, b, of the ground the visual ray corresponds. Repair there, we shall have ascended a distance = the height of the eye above the ground. Start afresh, from b, and in this manner the number of stations made between A and B, multiplied by the height of the eye above ground, will give the difference of level required.

(113.) The chain may in some instances serve us as a levelling instrument (48), to measure heights, but a clinometer should be preferred. The next example will serve as further illustration. To find

Fig. 124.




the height, AH , of an inaccessible steeple, A , situated on a slope.

Measure any line, C D, in any convenient spot, bisect it at O, march from D towards A, measuring any length, D E, trace O E, and produce it of an equal length, O F; trace C F, and produce it till it intersects the direction O A, in B. Then $O B = O A$, and distance, B A, is known.

At any point, a, of A B, plant a pole of such a length, that the eye at B may see its top in line with H. Measure a B and a h, and $AH : ah :: AB : aB$.

(114.) The difference of level between any two points may be found with the plane table. Referring to the instrument of Major Fèvre (90), we find that a wooden plummet in the shape of a ruler can be suspended in o. Stationing at one of the points, at A, we hold the table in the left hand, and aim along the side, A C, to the second point, B; the plummet remaining vertical, the angles p o q and D A B are equal.




If we carry from o to d , a distance, do , equal to the projection of AB , the triangle ogd is similar to BAD , and the line gd measures the difference of altitude required. Instead of carrying from o to d the projection of AB , we may carry on om any multiple, M , of it, and afterwards holding the table in the right hand, the plummet will take a symmetrical position, oq' , and the distance, nn' , will be

2M times the difference required. The graphical error is thereby diminished.

As, however, it is impossible to reach the point *o* on account of the screw, the distance *o p*, which is constant, is marked on *s s'* on the edge of the plummet. The multiple of the projection being then measured from *s* to *r*, the point *m* is fixed by taking $p m = s' r$. A slit cut through the plummet permits the introduction of the point of a pencil to draw the lines *o q*, *o q'*.

(115.) A clinometer has been constructed by Mr. Trinquier to obtain not only the angle of elevation, but also the horizontal and vertical distances between two points. It is contained in the lid of his prismatic compass, *P*, which is square, and it is kept erect by means of


FIG. 125.



a bolt, *R*. The bottom of this lid, *D*, is divided into two semicircles by a horizontal line, which we may call the fixed diameter. The lower

through the apertures m, m' , we know that cd is horizontal, and that both the fixed and the movable diameters coincide. Two thin strips of metal, $s s'$, are screwed to the sides of the lid; one of them, s , is pierced with a vertical and a horizontal slit, the second, s' , carries two hairs to correspond. The vertical slit and hair serve to take azimuths with the compass, and have nothing to do with the clinometer. It is evident that if we apply the eye to the slit q and look at an object until the slit q , the hair q' , and this object be in one line, the fixed diameter will be parallel to this line of sight, whilst the movable diameter remains horizontal. Thus the divisions of the instrument will always form right-angled triangles, similar to those on the ground: the movable diameter or hypotenuse represents the distance between two points, the fixed diameter or base measures the projection of the distance, and the perpendicular shows the vertical distance. An example will at once show how to handle this instrument. Suppose that the line of sight takes the direction $X Y$, the angle of elevation is at once given at Q . It is here

FIG. 128.



25°. Let now the distance from our station to the object Y be measured along the slope $X Y$, and let it be 220 yards, for instance. Assuming each division of the horizontal diameter to represent 10 yards, the graduation 22 coincides with the perpendicular 20, showing the projection or horizontal distance to be 200 yards. The vertical distance is read at the extremity of the parallel to the fixed diameter corresponding

to division 22. It is line 18, but as the intervals are only half the vertical ones which represent 10 yards, the difference of level is $18 \times 5 = 90$ yards.

To find the difference of altitude of two points when projections are fixed on the plan, we station at one of them and aim at the other. Suppose that the plan given is a horizontal distance of 190 yards: we find division 19 of the fixed diameter, and see where the movable diameter intersects perpendicular 19. If this point of intersection correspond to horizontal 12, the vertical distance is $12 \times 5 = 60$ yards.


CHAPTER IX.

MILITARY SURVEYING.

(116.) It has already been said that the first step to be made in a military survey is to select and measure a base (43) and by means of angles to construct a canvas connecting the important points of the ground. As the triangles should be of the equilateral form, it is advisable, when time allows, or when the plan is to be made with accuracy, to spend a day over the ground and make a provisional triangulation, indicating approximately the form of the triangles, and thereby enabling us to select the points which will serve to construct the definitive canvas.

This preliminary operation is accomplished as follows: we repair to the extremity, A, of the base we intend selecting, and draw a line on the centre of a piece of paper that will represent the direction, A B, of


FIG. 129.



this base; having then placed this line on the same vertical plane with its homologous line on the ground as explained before (84), and aiming successively with any ruler (82) at the points C D E F, or guessing (135) at the angles they subtend, we draw the lines A C, A D, A E, A F.

Proceeding to B we repeat this operation on another sheet of paper,


FIG. 130.



aiming at the same points as before, and to others if any are to be seen.

Transporting ourselves to another station, E, &c., we continue to


FIG. 131.



protract the angles observed at every station on distinct pieces of paper, until we have been over all the ground which we have to survey.

At home, we assume any length, A B, for that of the base, and transfer round the point A all the angles measured in sheet 1st, which is

FIG. 132.



easily done by placing A on a and A B on direction a b, and pricking with a pin a point on each of the directions A C, A D, A E, A F.

With sheet No. 2, we place B on b, and B A along the direction b a and transfer as explained all the angles observed at B. Several points, c, e, d, f, are thus obtained by intersection, and not to lose them it is usual to surround them with a little circle.

With sheet No. 3 we place E on e, and E A on e a, and continue to transfer the angles. Thus we obtain the relative position of the points of the canvas, and ascertain the form of the triangles.

(117.) The definitive stations being selected from this provisional canvas, we measure the base and draw it at the scale on the minute, and afterwards proceed successively to every station where we accurately observe and protract the angles. According to circumstances the plane table, prismatic compass, or sextant, will be employed for that purpose ;


but we readily appreciate the value of the two former. The base, which should be in a central position, is measured either by chaining or pacing. When time is failing we can procure the base from a map of the locality, and the canvas is at once plotted without any preliminary operation. The canvas itself might eventually be procured from a map, but as the points thus found are generally inaccessible, it becomes necessary to determine by means of them the position of accessible stations (18, 76, 88).

The canvas is the most important part of a survey, and we should take the greatest care to make it as exact as the instruments and time at command will permit; it will in the end save much trouble while filling in the details. The objects visible from a long distance, such as steeples, chimneys, remarkable trees, peculiar signals, &c., should be most carefully fixed on the minute, and besides those we should also determine the turnings of high roads, the points of entrance of a road through a wood, a village, &c., and the summits of hills, intersections of valleys, &c.

(118.) When the canvas is completed, it is usual to trace on it the direction of the true north. If the base has been taken from a map ready made, its azimuth is easily found thereon; but if it has been laid down from actual measurement, we trace a meridian on the ground through the extremity of the base or of any line of the canvas, and protract on the plan the angle formed by the two directions.

To trace a meridian on the ground, plant a staff vertically, and

FIG. 133.



describe from its foot as centre several concentric arcs. A little before


and after noon observe the course of the sun, and mark the intersections of the shadow of the staff with those arcs. Bisect in M , M' , M'' each of the arcs $m n$, $m'n'$, $m''n''$, &c., intercepted by this shadow, and those points M , M' , M'' belong to the meridian.

The meridian may also be traced directly on the minute by a similar process, by driving a pin, for instance, to replace the staff, but the minute should be placed in a position of parallelism (84).

If there is no sun, or if time must be saved, the prismatic compass gives us the magnetic azimuth of a line of the canvas, and we conclude the true azimuth by adding or subtracting the variation.

The polar star may also help us to trace the meridian approximately, for it is very nearly in the true meridian when it arrives in the same


FIG. 134.



vertical as the star E of the tail of Great Bear. A plummet enables us to ascertain the position of verticalism.

(119.) When a survey is very extensive, several officers concur to its execution; the canvas is first made on a single sheet, and is afterwards transferred to the several minutes, but in order that those individual surveys may afterwards agree, the transfer of the points is made

FIG. 135.



by means of their co-ordinates referred to two rectangular axes drawn

across the canvas, representing generally a meridian and its perpendicular. Thus the canvas on M N is subdivided into four sheets; on which the details can simultaneously be filled in, and these four minutes being placed close together will give the general plan.

(120.) Having in hand a minute with several points fixed upon it by the triangulation, we proceed to fill in the details.

The prismatic compass is undoubtedly the most eligible instrument for that purpose, but one should not exclusively trust to it, because in case of accident, and accidents will occur in the field, the operations would be interrupted. A previous acquaintance with the plane table, or the chain, the sextant, &c., will in such case prove of great service; but above all the plane table should be well understood, inasmuch as being replaced by the minute itself (82) it can never fail us.

To survey the details with a prismatic compass, we station at a point from which they are easily reached, a crossing or change of direction of roads, the entrance to a village or wood, the corner of a wall or of an inclosure, &c. We determine on the minute the projection of that station by taking two or three bearings on the points already given (76), and we proceed as described for traversing; we frequently check our work by taking bearings on the points we have previously found; and by pacing the distance at every station to the various details, we successively introduce them, and even draw them at sight between two stations sufficiently close to each other. The method of intersection is to be had recourse to whenever possible.

To fill in with the plane table, we select the same points, and find our station as explained (84, &c.), introducing the details by intersection, by chaining or pacing, and traversing on the chief direction.

With a box sextant the operation is more troublesome, but the principle is the same.

(121.) Whatever instrument we employ, we must frequently verify our position on the survey by means of those points of which we are certain, otherwise the errors will rapidly accumulate.

We lay down the trees, embankments, ditches, rocks, &c., and indicate the various kinds of culture by initials, to figure them afterwards according to the conventional signs.

The chief objects to determine exactly among the details are the

roads, paths, openings through forests, rivers, rivulets, lakes, pools, fountains, streets, outline of towns and villages, isolated buildings, mills, churches, castles, bridges, &c. ; and while filling in these details we note in our pocket-book all the information that will subsequently enable us to write our report.

For rivers, we follow one side by *traverse*, and determine the other by intersections ; for rivulets we also fix some points of their course by means of bearings, and have recourse to the cross-staff (105) when advantageous.

For towns or villages, the outline is first surveyed, and the entrances of the chief streets accurately fixed : then we engage in one of those thoroughfares, and while traversing we protract every detail by pacing the perpendiculars dropped from them to the direction we follow. After this we start from a central point, such as a square, a church, &c., to the various outlets. The yards, gardens, &c., are subsequently drawn at sight. The masonry is marked by a thick line, and the houses are shaded, so as not to be confounded afterwards with the yards.

The woods and forests are plotted in the same manner : first the perimeter ; then a road, then the various outlets.

It would be impossible to enter into the never-ending particulars of the filling in the details. A day spent in the field with a brother officer well acquainted with the practice of military surveys, will do more for the instruction of the beginner than volumes of text. The principles of planimetry are both simple and few ; the instruments employed are easily handled ; but it is left to the sagacity of the officer to make the best use of those tools by an intelligent application of the methods previously described. Nothing is more simple, and the problem becomes still easier if the surveyor brings to bear on his work all the accuracy allowed by the instruments he employs. Accuracy is a saving of time and trouble.

(122.) To complete the survey it is necessary to represent the undulations of the ground, and to give the relative height of every point of its surface, together with the direction of the acclivities and declivities.

To effect this we begin by determining the altitude of a few of the


points obtained in planimetry, in order to form what we may call a canvas of levelling. If the altitude of one of those points is known, we obtain that of the others by means of the angles of elevation (110). If it is not known, we assume a certain value for it and calculate the others; for in military surveys all that we require is the relative height of the different points, and it matters but little whether it is possible or not to obtain from a map or any other source the true elevation above the level of the sea.

(123.) Having carefully established this canvas, we proceed to fix the position of the highest and lowest points of acclivities, that of ridge lines, thalwegs, cols, and of all points at which there is a change in the intensity of the slopes, which have not already been determined in planimetry. Their accurate position on the minute is indispensable for fixing the projection of their respective distances.

This done, we station with the clinometer at the points of known altitude, measuring the angles of elevation or depression, and by means of the formula $H = D \tan a$, or the table (110), or even by a simpler process (112), we find one by one the altitudes of the various points which have been enumerated, and it is advisable to verify the altitude of the important points by means of two others.

(124.) When this is completed, we figure the undulations by the contours, an operation which is much simplified if we have, while stationing on any point, indicated the direction of the slopes. In fact, an officer accustomed to survey will have done so even in plotting the planimetry. The best way to mark this indication is to look in four

FIG. 136.




perpendicular directions, and figure by little arrows the direction

H

the reading. The man moves afterwards in the vicinity of A, until the same reading be again in sight with the level: the point C, where

FIG. 141.




this occurs, is evidently on the same level with A, and the man plants a stake thereat: on he goes, and as many points as are wanted are fixed in this manner. The same operation is repeated for contours 70, &c. Having thus traced the contours on the ground, they are plotted on the minute, with the help of the prismatic compass to take the bearings of the stakes.

This method is long and tedious, therefore the second will be preferred as more expeditious, and sufficiently accurate for general purposes.

(126.) Suppose that the altitude of the points a, b, c, d, e, &c. (Fig. 142), has been ascertained (122), and that the equidistance=10 yards. Join those points by straight lines. The point a is on a contour, but h is not, and there will be five contours between it and a. Divide a h into six parts, five of them equal, and the rest only $\frac{1}{6}$ (Euclid, p. lvi.), the contour will pass through the points of division. Again, take b c, and divide the line into six equal parts, if the sketch (124) indicates a uniform slope. Along a d the sketch implies a greater declivity towards a; divide, then, a d, by sight, into six unequal parts, the smaller being nearest to a; divide m n into three equal

parts, and if the sketch indicates a continuance of the same slope above *n* and below *m*, carry another division beyond those points, and so on.


FIG. 142.



The points of same altitude are afterwards connected by a continuous line.

(127.) The clinometer of Trinquier will here be found very convenient. By means of the pins of the movable diameter (115) which determine a horizontal line, we can trace one contour as already explained (125). Let A B C D E be this original contour, and let

FIG. 143.



the equidistance be five yards. Stationing at A we aim with the horizontal slit along the steepest line of the slope (or the less steep, as the case may be), as far as we can see the dip uniform. Let the

angle of depression be 25° (Fig. 128). The parallel 10 intersects the movable diameter at a point corresponding to perpendicular 11 of the fixed diameter. This shows that for a distance of 110 yards the vertical fall is $10 \times 5 = 50$ yards, or that for 11 yards measured horizontally the dip is 5 yards. Hence, if on direction A A' of the dip, placed on the plan by means of the compass, we take parts of 11 yards each, we obtain as many points belonging to the contours required. Stationing now at B, we repeat the same operation: if the parallel 10 intersects the movable diameter at a point corresponding to perpendicular 20, then on B B' the contours will be 20 yards apart, and so on.

(128.) The operations of levelling as described here should be made by beginners *after* they have completed the planimetry: but when they have, by means of practice, acquired a fair acquaintance with the forms of the ground, they may venture to conduct planimetry and levelling abreast. In military surveys they will be expected to do so, because the exactitude of the contours is not necessary, the chief thing consisting in indicating the relative heights, so as to distinguish those practicable to the three arms from those that are not. Therefore, whenever making a station in the field, we must sketch the features of the ground around it, and when repairing from one station to another, endeavour to connect those indications by slight touches of the pencil, to be afterwards modified when the clinometer shall have come into play, and given the altitude of a few stations on the thalwegs, ridges, summits, cols, &c. Let us here more than ever beware of the field book; never trust to memory if we can help it, and constantly draw the features from nature. There lies the real study of topography.

(129.) When a survey is made for a special purpose, it is customary to compile a memoir to complete the description. The table (141) contains all that is necessary.

CHAPTER X.

MILITARY SKETCHING.

(130.) It very seldom occurs that in the field we have either the time or the means of executing regular surveys; and as plans are necessary to guide the movements of troops, prepare their encampments, select positions, combine attacks on field works or passages of rivers, &c. &c., it becomes indispensable for officers on the staff to make those plans or sketches either without instruments, or merely with those that they can construct themselves on the spot.

Nothing is impossible, especially in topography; and whatever be the circumstances under which an officer is placed, he should never give up an attempt as useless until he has tried. And if he tries, he will succeed.

Referring to the foregoing chapters, all that is required to make a plan is to measure distances and angles. For distances, we have three means—our pace, the trot of a horse, or our watch—the first of which cannot fail. For angles, if a prismatic compass or a sextant cannot be found, a plane table can be improvised, and it is indeed a capital instrument. A cross-staff and a clinometer are made in a few minutes. If we employ this rough table a pin fixed into it shall provide us with a sundial which will still simplify the operation. With paper, pencil, india-rubber, and a knife, we have the wherewithal to proceed.

A previous acquaintance with the principles of topography, and a fair amount of practice in regular surveys are indispensable, since in every sort of sketch the art consists in making the best possible attempt at imitating the regular process, according to the resources at hand. A few words will be sufficient to point out what is to be done when we have contrived to extemporize our instruments, and have time enough to take measurements, or when, being hurried, we have scarcely time enough left for that purpose.

(131.) The first step to be taken is again to select a base and form a canvas. Sketches are generally made at the scale of 4 inches to the mile, but we adopt the scale of paces and construct it at once. If a map can be obtained we transfer the base as well as the canvas on our minute, selecting for vertices of the triangles the steeples, windmills, bridges, or crossings of roads. But as this is possible in Europe only, we are almost always compelled to measure the base and to construct the canvas by one of the methods which have been explained: if the country is woody or barren we plot the triangles by pacing—a long but then indispensable process, which can nevertheless be simplified in employing men to signal remarkable trees or to stand for points of triangulation.

(132.) The details will afterwards be filled in, and as this operation will be so much the easier when the canvas is well and closely executed, we could not pay too much attention to its construction. The methods of intersection in open countries, that of traversing in woody ones, are successively or simultaneously employed. Starting from one station we proceed to the next, drawing details at sight, right and left of the direction we follow, occasionally climbing a tree to discover them better.


With regard to the representation of the relief, the canvas contained some points on the characteristic lines of the undulations, thalwegs, ridges, and on summits. An arbitrary altitude being assumed for one of those points, the height of the others will be ascertained by means of the clinometer. The details of the relief will be plotted by figuring at every station the lines of contour and the directions of the acclivities (124). It would take more time to describe all the operations of such a survey than to make one. We shall therefore confine ourselves to a few remarks.

(133.) The details of every triangle are filled in by following first the direction of the perimeter, then a direction either road, thalweg, or ridge, running across it, laying down the details at sight, subdividing the triangle into two parts. Those are again subdivided in the same manner until the parts become sufficiently small to permit drawing at sight whatever they contain.

We should not hurry in attempting to represent too much at

a time on both sides of the direction we traverse; it is far better to indicate them slightly at first, and definitively plot them when their position has been verified by that of the other roads or directions between which they are contained. These roads should be traced according to their general direction; this is important, inasmuch

FIG. 144.




as there is a tendency among beginners to exaggerate the windings and to represent the road A B as a b.

For a village, it is advantageous to make a preliminary reconnoitring from the top of a high building or a steeple. We trace its chief street; then, if possible, two streets at right angles: after this, we take the perimeter of each part, and subdivide it till the details can be drawn at sight. The same of a wood.

In figuring the relief, we should remember that we have a great tendency to exaggerate the importance of the acclivities on which we are placed, especially when the ground presents slopes alternately


FIG. 145.



gentle and steep; so much so that the slope B A is often estimated to be on the opposite, A' B'.

When following a thalweg, T, slightly pronounced, having for


FIG. 146.



instance a mere depression of two yards, we are inclined to exaggerate it as in T'.

We are also invariably inclined to open the valleys too much, and this may be avoided by determining carefully the position of

FIG. 147.



the lines A B, A' B', on which the slope of the sides changes its direction.

(134.) When the enemy is close by, a survey at sight or a sketch is the only representation that can be made when any information is needed respecting the ground, and as time becomes precious, the foregoing operations can no longer be made. Here the *coup d'œil* is indispensable, and if an officer has not by a long practice become familiar with valuing distances and angles at sight, he will vain attempt such a reconnoitring.

Although such surveys generally embrace but a limited extent, since they would otherwise be far too inaccurate, yet a method of measurement should be adopted, because perspective would tend to accumulate errors upon errors—there being no absolute, but only relative, dimensions for the eye.

The means employed differ but little from those employed in topography. We select and measure a base, and connect it with the different points of the surface by climbing a tree or ascending a culminating spot. Or we select three conspicuous objects, measure by


time their respective distance, and plot the triangle at the scale. Starting from one of the corners, we advance towards the other, drawing at sight all the angles. Having done so round all the perimeter, we proceed to the interior. The undulations are figured at the same time, but, as it is only necessary in this case to "accuse" the relative heights, this is done by making the hachures thicker when the slope is steeper. Numbers 1, 2, 3 may be inscribed on the minute to denote the heights in relation to their importance. Great attention is paid in distinguishing the acclivities practicable to infantry, cavalry, and artillery from those that are inaccessible.

Perspective leads to many illusions; a steep hill appears nearer than it is. In some instances distance seems greater at dark or in foggy weather—a smooth object appears nearer than a rough one; the dimensions seen from above seem smaller than those seen from below. No attempt should, therefore, be made to guess beyond a mile.

(135.) The officer who is liable to be called on to execute this sort of survey should exercise his sight, and know at what distance he no longer distinguishes a man, a horse, a tree, a house, &c.; this alone may help him greatly.

Angles must be guessed at. Among the many means employed to obtain them, we may notice the following:—

FIG. 148.



Two pieces of wood, two rules, for instance, are fixed together at right angles in a : the side $ab = ac = ad$, and $ae = \frac{1}{2}ba = \frac{1}{2}ca$. Pins being planted at b, e, c, d , this contrivance will be employed as the staff cross (97); it gives several angles— $bde = edc = cbd =$

$bcd=45^\circ$; $ebc=ecb=30^\circ$; $bed=dec=60^\circ$; $ebd=ecd=75^\circ$; bdc
 90° ; $bec=120^\circ$. It is the *winkel kreutz* of the Germans.


A foot-rule with a hinge, or a piece of paper folded, may serve to measure and trace the opening. A square piece of paper folded in

FIGS. 149 and 150.




half along AB , then folded in $\frac{1}{2}$, $\frac{1}{3}$, &c., gives angles of 90 , 45 , $22\frac{1}{2}$, $11\frac{1}{2}$ degrees; and those of $78\frac{1}{2}$, $67\frac{1}{2}$, $56\frac{1}{2}$, $33\frac{1}{2}$, are obtained in opening all but one or two, &c., of the folds.

FIG. 151.



The forefinger and thumb of the arm extended to their utmost stretch subtends about 11° .

FIG. 152.



These auxiliary means will guide the observer, but he should exercise himself in guessing at a few angles round the whole space, and

correcting his valuation by the excess of their sum over 360°. Taking first 4 angles, then 8, then 12, his eye will gradually gain experience. Indeed, it is surprising with what accuracy some practised officers value a series of angles at sight.

(136.) Among the many cases that may occur, the reconnoitring of a road (77) through which a convoy or a detachment will have to pass, happens frequently. It is accomplished by traversing, guessing at the angles formed by the windings, and sketching the details at sight within a few hundred yards on both sides. This sketch, or *itinéraire*, as it is called, is accompanied by a report giving the distance between the most remarkable points, such as villages, defiles, bridges, ascent, descent, change of direction, buildings, cross-roads, &c. It will state the time employed to perform the journey, give the width of the road, indicate its nature, &c. The objects having military importance should be described: villages, houses, rivers, bridges, fords, &c.; the accommodation for man and horse either on the march or in permanent quarters likely to be found in the villages; the means of transports, such as horses, carts, ferries, &c.;—in a word, everything we can learn or see should be noted. (See 141.)

(137.) It may happen that an officer has not even the time to survey in this manner, and that he is placed in such a position that he cannot ostensibly make use of his pencil. This most generally occurs under very important circumstances—in the proximity of, if not under the very eye of the enemy. To memory alone he must trust; therefore it is indispensable that he should understand thoroughly the object of the reconnoitring, in order to concentrate his attention on those points of the ground which possess importance. He should notice the time he took to walk or gallop to the chief points. He examines the state of the roads, the direction and inclination of acclivities, the rivers, rivulets, and their embankments, &c. &c. Returned at the camp, he should plot the chief objects in translating the time into distance, and group the details around them. This sort of survey is closely connected with military art—in fact, it belongs to it.

(138.) A rough sketch may even be had from mere indications, previously to entering a country occupied by the enemy: spies and inhabitants, especially guides, hunters, carriers, muleteers, shepherds, &c., are

examined separately and cross-questioned as to the roads and paths, the places they lead to, the obstacles, defiles, woods, hills, rivers, marshes, bridges, &c. The sketch is made under the eyes of the informer, marking the distances in time, and it is successively rectified.

(139.) *Reconnoitring* is the *ensemble* of the operations necessary to obtain information on the nature of the country on which the war is carried, on the resources it affords, or on the forces and positions of the enemy.

Generally, reconnoitring will consist of two distinct parts, 1st, a plan or sketch ; 2nd, a report.

According to circumstances, the sketch will be one of those we have described.

As for the report, it should contain a brief account of all that bears upon the end in view, distinguishing *most* scrupulously that which has been seen from the information collected from various sources, but not verified personally.

An officer entrusted with a reconnoitring receives some special instructions from his commanding officer: to them he must implicitly conform, without attempting to swell his report by details unconnected with the purpose of the reconnoitring. It is not an easy task, to seek for, to take, and to collect the information required ; it implies a vast experience: therefore, to accomplish it with credit, we should during peace prepare ourselves by several exercises on the ground, and by reports on some special cases connected with the arm of the service to which we belong.

To take and collect information at home is difficult, because when the inhabitants perceive officers engaged in the act, they grow suspicious lest some new billeting or some tax be imposed upon them: but in a hostile country it is far worse—so much so that they conceal all they can, and invariably affirm that the “environs” of their village are impracticable; hoping thus to deter the troops from approaching them. Even when of good faith they give out to be practicable the regular roads and paths only, and consider as great obstacles the ploughed lands, hedges, ditches, &c.; so that it becomes necessary to multiply the investigations in order to ascertain the truth.

While executing the plan or sketch, we collect and note all that

we see: we question guides, shepherds, carriers, as well as mayors, bailiffs, &c.; examine the maps in existence, the statistical, historical, and military works written on the country under investigation. If none can be found, we endeavour to extract statistical information from the inhabitants themselves—this skilfully and indirectly—avoiding to frighten them or to rouse their suspicions. To this end a fair knowledge of the language of the country is indispensable.

(140.) For officers who have not yet acquired some experience in writing reports on reconnoitrings, we give a table of the different subjects to be examined in the most general cases, as adopted in the French staff. They are enumerated in the order in which they should be treated. It will be sufficient for the most extensive memoirs, and for any special case, such as the reconnoitring of rivers, roads, &c. The points to which attention should be directed are found under the proper heading, if they are not mentioned in the order given at starting.

This report is written legibly, with conciseness and lucidity. Proper names should be carefully spelt. The order in virtue of which the operation has been made is transcribed at the head of the manuscript, which is made up as a report, not as a letter, and signed by the officer.

§ I.

Physical Description.

(141.) *Geographical Position of the Ground reconnoitred.*—Approximative limits between which the ground reconnoitred is enclosed. Latitude, longitude, and if possible, altitude of the chief point; general watershed; boundaries of the coast, of the watershed; principal basin to which the ground belongs.

General Configuration of the Ground.—General aspect; mountainous, hilly, or level; open or wooded; of easy access, or intersected with obstacles, hedges, ditches, enclosures, walls, rocks, &c.; covered with bares or heath; dry or marshy.

Basins, Orography.—Basins in which the ground lies. Chains of mountains and their ramifications; chains of hills and of secondary heights; of what description. Table-lands, their form and area. Direction of the watershed lines; remarkable points through which

they pass; greatest altitude; table-lands or heights across which they run.

Valleys, vales, ravines, defiles: their dimensions; height of the sides, and steepness of their acclivities; great undulations which destroy their regularity or obstruct the circulation; eminences or buttresses narrowing or running across the valleys; forests; lakes; marshes; &c.

Plains.—Level, undulated, intersected with hills, ridges, bares, marshes, &c.

Maritime or fluvial islands.—Their dimensions; mountainous, flat, marshy, or sandy; wooded; cultivated or barren; inhabited or not; towns, villages, anchorages; to be described as a continent when their surface is uneven; floating islands.

Hydrography.—Rivers and streams running across the ground reconnoitred; their source; total length of their course; chief towns situated on their banks; their mouths or confluences; principal tributaries.

On the ground reconnoitred itself: breadth and depth; variations they are exposed to at different seasons; parts where the river is fordable, and its depth; variations of the bed; places where the stream branches off; importance of the branches; height of the banks; fall per mile; sudden variations in the channel, falls, rapids, eddies, rocks; velocity per hour; periodical or accidental rises; their cause; time at which they take place; their height above low-water mark. Inundations: how far they extend in the valley; mention of extraordinary floods, and the places which suffered most; how to prevent their recurrence; dams, sluices, &c. Nature of the bottom of the river: rocky, gravelly, sandy, muddy. Nature of the banks: their form; flat, gently or rapidly sloping, abrupt, overhanging; height above the water; covered with stones, woods, meadows, reeds, or gardens. Command of one bank over the other; constant or alternate.

Canals: their name; where they lead to (see § III.).

Lakes: their dimensions; nature of the bottom and of the banks; fordable parts; navigable parts; ports, capes, isthmuses, and other peculiarities.

Ponds: artificial or natural; permanent or not; easy to empty or

otherwise; if the bottom be practicable for troops; produce of fisheries, cultivation; influence on the health of the inhabitants.

Marshes: produced by streams or by springs; covered with water or mud; their extent; if there be any secret or open communication across; possibility of draining them. **Bogs:** their extent; passable or not; if turned to any account.

Swamps, pools: how made use of by the inhabitants; their influence on salubrity.

Fountains and springs: whether numerous and of abundant supply; potable, saline, or muddy water; chief ones to be indicated; their temperature, when it differs sensibly from that of the atmosphere; use the inhabitants make of them; remarkable peculiarities; intermittent and spouting fountains, &c.

Cisterns, artificial or natural wells: if they give a sufficient supply to the inhabitants. **Artesian wells;** their depth; abundance and quality of the water. **Pits.**

Sea Coasts.—Configuration of the coast: cliffs or downs; their height and shape; if worn away by the sea; marshy, gravelly, or sandy shore; even or undulated beach; natural ports, harbours, anchorages, roadsteads, creeks, bays, &c.; points favourable for landing; advantages for navigation; works of art constructed to resist the encroachments of the sea; depth below which the vessels cannot enter the port; sands and bars near the coast and at the mouth of navigable rivers—this mouth to be described; difficulties attending the entrance of vessels into, or their egress from, the river, either on account of the ground or the winds and tides; mention if the bars are changing, and if the passage is more practicable at one time than at another; lights and signals, either extant or to be established.

Nature of the Soil at the surface or at different depths. Grottoes and caverns; their extent; to what account they could be turned. Subterraneous streams and lakes. Geological composition and mean thickness of the vegetable soil in the plains and on the acclivities.

Volcanoes, either extinct or in activity; volcanic formations. **Craters,** their situation, height, and shape. **Basalts, lava, dross, &c.**

Ores of every description, either under work or not. **Mines;**

coal mines; their depth, number, and thickness of the strata; quality of the products.

Quarries of marble, stone, chalk, gypsum; those that are worked; quality of the products.

Mineral and thermal springs; nature and quality of the water; the account it is turned to.

Salt pits; salted springs; salt marshes.

Aerography.—Climate; warm, cold, dry, damp. Mean barometric pressure. Temperature of the various seasons; mean temperature; greatest cold; greatest heat.

Number of wet days; mean quantity of rain falling in the year; how long the snow remains on the ground; rivers which freeze so as to bear loaded carriages.

Prevailing winds. Fogs. Properties of the air and water with regard to the health of men and animals. Endemic diseases; causes of insalubrity; how to remove them. Meteorological facts—Violent and frequent storms, hail, waterspouts, &c. Plants and animals peculiar to the climate—Rye, wheat, rice, vines, orange trees, cochineal, &c. Forests—Fir trees, &c. Race of men, of mammalia, reptiles, &c. Tides—Their chief peculiarities; limits of high and low water in the ports and the rivers.

§ II.

Statistics.

Political and Administrative Divisions.—Ancient provinces of which the ground reconnoitred has made part. Administrative, judicial, ecclesiastical, military, maritime, and financial circumscriptions. Counties, departments, cantons, provinces, districts, unions, parishes. Courts of appeal and sundry tribunals. Dioceses, consistories. Universities, academies, consulships. Sundry services—Postal service, high roads. Mines. Woods and forests. Custom-houses for direct and indirect taxes. Divisions or military stations—Artillery's head quarters; engineers' head quarters. Maritime prefectures, districts, and quarters.

Population.—Total population of the canton, parish, district, or

other circumscription. Distribution of the population between the towns and country; between agricultural and operative pursuits; between mountainous and level countries. If the population is increasing or decreasing. Comparison between the existing and a previous state. Causes of the movement of the population. Number of inhabitants per square mile; number of families. With regard to recruiting, compare the number of men with the amount of the population. Proportion of men declared fit for service to those examined. Average height of recruits. Proportion of men fit for the special arms of the service—artillery, cavalry, &c. Height, physical constitution, character, manners, way of living and dress of the inhabitants.

Differences or homogeneities between the inhabitants. Sympathies or antipathies between divers classes of the population, and divers localities. Aptitude of the people for war, arts, sciences, commerce, or agriculture. Emigration—Workmen going to other countries, or coming from neighbouring states; for agricultural or industrial pursuits; extent of emigration.

Militia, Yeomanry.—Organization into legions, regiments, battalions, squadrons, or companies of cavalry, infantry, artillery, firemen. Force per county, district, parish, or other circumscription. Number of men forming part of the reserve of the army with unlimited leave of absence. Maintenance and state of the armament at the charge of the states, communities, or private persons. Clothing. Parts of the militia wearing uniform. Degree of military instruction. Aid which the armed population would afford in case of need.

Language.—Languages and dialects; parts of the population who speak them. Usual way of spelling the names of places; their pronunciation, when it differs from the ordinary language; etymology of the names of the principal places. Characteristic words to be found in the language of the country. Examples.

Religions.—Divers sects; number of inhabitants comprehended in each; their reciprocal disposition.

Public Instruction.—Degree of instruction of the different classes of the population; proportion of literary persons. Schools of all sorts. Literary wealth of public libraries. Universities. Academies. Learned societies.

Public Buildings.—Churches or temples, castles, town-halls, courts of justice, colleges, seminaries, museums, libraries, exchanges, markets, light-houses, prisons, &c. Remarkable houses or buildings; their construction or their historical importance. Their use and capacity. Objects of art esteemed.

Houses.—Different habitations, country houses, farms; their general distribution and size; if built of stones, bricks, earth, wood, &c.; tiled, or thatched.

Resources for Lodging Troops.—Estimate of the resources for men and horses. For troops on the march or quartered; whether in military buildings or other public establishments, or in private houses; large buildings fit for the reunion, in a case of emergency, of a large body of men or horses. Localities in which small buildings only are to be found. Military establishments, hospitals, parks, magazines, &c.

Materials of Construction employed in the Country.—Marbles, stones, bricks, udders, &c.; timber and other woods; metals; quarries whence the materials are extracted.

Statistics of Towns.—Capitals of counties, departments, fortified places, garrisoned or maritime towns, and all towns having more than 3000 inhabitants. Situation—Advantage of the position of the place, whether as a fortified place or a centre of industry, commerce, &c.; as a seaport, on a river, on a railway, at a cross-way, in a fertile country, &c.; its distance from neighbouring towns; aspect of its buildings in general; their mode of construction, resources which they would offer for the different military services. Enclosed or open towns; shape of the enceinte; ancient or modern fortifications; walls; enclosures; divers authorities who sit in the towns; details of the population; on the various public establishments; distribution of the waters; industry; commerce; celebrated men of the country.

Particular statistics of fortified places; system of fortification; number of fronts of the enceinte, outworks, ravelins, counter-guards; detached works—their form and importance; if the place is protected by a river, by inundations, marshes, escarpments, &c. Military buildings bombproof; casemates, resources offered for all military services by private buildings and houses.

Agriculture.—State of the agriculture of the country; general

aspect of the situation ; progressing or falling off ; quality of the soil, wheat, rye, or barley land ; vineyards, meadows, woods, &c. ; high or small farming ; methods of cultivation, whether by horses, cattle, or hand ; harvest rotations ; customary crops of the land ; artificial meadows ; varieties of agriculture ; proportion of the sowing to the reaping ; produce per acre of cultivated lands, meadows, vineyards, orchards ; mention the various products—hemp, linen, oleaginous plants, beetroots, tobacco, &c. ; ratio between the production and consumption.

Woods and Forests.—Forests of public domains ; public and private woods ; what natural productions predominate ; high forest-trees, copse, or underwood ; regulations adopted for cutting ; statement of the size and condition of the forest ; thickets, glades, cultivated lands, meadows, ponds, and habitations which they contain ; their products ; practicable or not for troops, for artillery ; cross-roads, trenches, water-courses, ravines, ditches ; wood fit for ship-building, or cooperage.

Cattle.—Different races of horses ; the breed progressing or decreasing ; qualities and faults of these races ; approximate number of the kind fit for military service ; saddle and draught horses ; paddocks, stallions' dépôts ; number of horses they furnish ; mules and asses in the country ; bovine race ; number of heads of this race compared with the population and the wants of agriculture ; its qualities ; fleecy beasts ; existing races in the country ; approximate number of heads or of flocks. Goats, only when they are in flocks.

Products of the poultry yard, the chase, and fishing (when commercial) ; fowls, pigs, game, fish ; butter, eggs ; dairies, cheese-markets, bee-hives, oil, fruits, &c.

Industry.—Hand-mills, wind-mills, water-mills, steam-mills—their situation and productions ; other mills ; oil-mills, tan-mills, saw-mills, &c.—Paper factories ; their production ; hand or mechanical fabrication ; founderies and metal works ; salt-pits ; wool, cotton, linen, silk, hat, rope, tan, &c. Factories—china, pottery, bricks, tiles, &c. ; works—their importance ; number of workmen they employ ; works made by hand, with horses, water, steam. Annual natural productions ; annual time of rest.

Local measures of length, superficies, weight, capacity ; their relation to standard measures.

Commerce.—Agricultural, industrial, native, exotic productions. For consumption, importation, exportation, transit; docks, warehouses, &c. Annual variations of import and export; fairs and markets for grains, beasts, &c. At what time they take place; their importance.

Public Revenue.—Direct and indirect taxes; custom-houses, &c.; outline of the working of the establishment of taxes; revenues from domains belonging to the State; do. of the branches of industry and commerce of which the State reserves to itself the monopoly; resources of credit.

§ III.

Communications.

General Outline.—Network of the communications; high roads of divers classes, roads more or less numerous, more or less practicable; railways; navigation; telegraphs.

Land Communications.—Details concerning each of the high roads most important for military operations which are to be mentioned in the *Mémoire*; general direction, breadth; paved, strengthened with flints, or, in the old way, on natural earth; sided with trees, hedges, ditches, walls, poles; hollow or banked up; slope for the drag; low parts which could be overflowed; other causes for accidents; defiles; facilities or obstacles for waggons; distance between one town and the other, and to those to which the road leads; how frequented; post inns, public vehicles, waggons. Means for repairing to be found in the country; parts of the road running upon old Roman ways.

Roads of Second Order (?)—Principal details of the preceding article according to the military importance of the routes. Divers routes—on fascines, on ice, &c., &c. Neighbouring roads fit for waggons as distinguished from those merely destined for beasts of burden or foot soldiers. Footpaths.

Railways, either constructing or worked; principal towns they pass through; where they end. Branches. Importance of a terminus as a point of concentration. Lines, with one or two sets of rails. Distance from one terminus to the other; total length. Slopes or inclination of the ways. Obstacles that they pass—Rivers, mountains,

forests, &c. Appointed time for the journey. Mode of construction—On soil, viaducts, arches, or tunnels. Engines. Employment of the railroad for the transport of travellers, merchandise, or for manufactures and metals. Influence of each of these roads over military operations (subject of § IV. of the *Mémoire*). Railways in project.

Navigation.—*Details on each of the practicable rivers:* limits and extent of the navigable or floatable parts; ports or landings; impediments or accidents of the ground which hinder navigation. Works of art for keeping up the navigation: dykes, sluices, locks, cuttings, weirs, &c.; cleansing, repairs, &c.; annual duration of the time of rest.

Number, dimension, and draught of water of the boats; burden in tons of the boats navigating by sails, steam, or by being towed; valuation of the annual transport of travellers, provisions, agricultural and industrial, native or foreign merchandise.

Canals.—Details about every canal passing through the ground reconnoitred; name and ends of the canal; if with points of division; lateral to a river, or joining two navigable ways; of great or little navigation; length, destination, and importance of the canal; chief towns it passes through; breadth at the level of water; depth; nature of the country it passes through; rivers or other waters which feed it; works of art for the canal, dykes, sluices, locks, &c.; distance between the sluices or locks; height of the fall at the locks.

Boats, and amount of navigation, as for rivers.

Maritime Navigation.—In ports, establishments of the royal navy, ships of war or belonging to the State. Number and tonnage of merchant vessels, of vessels that sail in and out annually. Number of sailors; seamen attached to the colonial or distant trade, to the coasting and fishing trades.

Means of passing Rivers and Canals.—General considerations on the points of passage. Existing bridges; their situation, length and breadth, their destination; their construction in stone, iron, wood, &c. Suspension-bridges of one or more arches; for carriages or foot passengers only; tolls. Drawbridges; lifting or turning bridges; small and foot bridges. State of repairs; means of repairing which the country affords. How to destroy the bridges.

Ferry boats, flying bridges. Time necessary for crossing. Number of men, horses, and waggons, that they can transport.

Fords, permanent or moving; their direction, perpendicular or oblique to the stream; quality of their bottom, rock, gravel, fixed or moving sand; their length and breadth; if they are fit for the passage of artillery, cavalry, or only infantry; means of rendering a ford impassable.

Convenient sites for military bridges, pontoons, boats, easels, &c.; length which those bridges would have; facility of approach; passage on ice.

Telegraphic Lines.—Aerial and electric telegraphs. Direction of the line. Principal towns where the wires end. Telegraph stations existing on the ground reconnoitred.

§ IV.

Military Considerations.

Offensive.—General character of the ground reconnoitred considered in a military light; advantages offered for operations by the great obstacles, communications, and points of support of which possession can be taken. Great lines of operation, sketch of the same; openings and masses of resistance. Secondary lines of operation. First and second-class strategic points to occupy. General outlines of the works of fortification and others to be proposed. On the maritime coasts; advantageous points for landing; tonnage of the vessels that can land; difficulty of approaching the coasts through winds, tides, &c.

Defensive.—Extent of the frontier in length and depth; general disposition of the ground; great undulations; openings; masses of resistance; lines of defence; protection to be derived from them; lines of operations by which they are intersected; strength of the chief base of operations, owing to the nature of the ground or to fortified points. Points of support for defensive operations. Communications (besides the great strategic lines already spoken of) perpendicular or oblique to the frontier that are more or less practicable; how to defend them. Probable direction of the attacks of the enemy; of an

invasion. Means of resistance to oppose him, or system of defence proposed in the *Mémoire*, according to the configuration of the ground, the communications, the defensive resources existing, and the military operations which the ground would allow of.

In countries difficult of access, mountainous, or covered with forests, thickets, or defiles; advantages of their organizing a guerilla warfare. Facilities for divers kinds of ambuscade; points of concentration, rallying-points. Resources of all kind (men, provisions, means of transport) to be drawn from the country and the inhabitants for this kind of war.

Near the coasts; maritime attacks to which they are exposed; points of landing to watch; system of defence to propose.

For the interior of the territory; lines of defence in the rear of the former; protection they would offer against the probable march of the invasion. Additional means of defence. Masses of resistance to be turned into account in the defence; works they would require. Defensive points to organize. Points of concentration of the movable forces, of the reserves. Decisive points of the theatre of operations.

Positions.—Positions for a *corps d'armée*, a division, a detachment more or less considerable, covered by natural obstacles or to be entrenched. Fields of battle, site for fortresses, entrenched camps, divers posts, &c. Details on the positions which the ground encloses, their action on the general defence; distance to the neighbouring fortresses; extent of the front, depth; obstacles covering the flanks and front; communications and lines of retreat more or less practicable; troops of all arms necessary to the defence of each position; safe site for the parks; advantage to be derived from cities, villages, castles, churches, cemeteries, for defence or shelter; places from which provisions, forage, water, and wood, could be drawn.

For a fortified or a maritime town: full information respecting the particular statistics, and application to this place of the above considerations; advantages or inconveniences of the disposition and construction of the works; flanking fire; defilade; strength and capacity of those works; their state of repair; front or fronts of attack; description of the environs, and statement of the difficulties for an enemy who undertakes the siege. For maritime places: if the naval establishments are

exposed to the effects of a bombardment, or of a fire from steamers or rockets; means of preserving them from the effects.

§ V.

History.

General History.—Statement of the principal political events that have taken place in the country where the ground reconnoitred is situated. Origin of the remarkable cities or of the actual population. Changes of governments the country has undergone; dominions under which it has passed. Great disasters that befell it. Celebrated politicians, or military men who influenced the state of the country.

Archæology.—Remaining monuments of the various epochs, Greek, Roman, Christian, &c. Each epoch divided into three classes—Religious monuments, military monuments, civil monuments.

Cities or villages, strongholds, castles, ancient camps, temples, &c.; their position, description, vestiges that remain of them. Authorities from which the description is taken, historians, drawings, traditions of the country, &c.

Roman ways passing over the ground reconnoitred; lines which they follow; where they lead to; their ramifications. Vestiges that remain of them. Nature of their materials.

Documents and historical materials existing in the museums and the public or private libraries. Printed works, manuscripts, drawings, engravings, and sculptures, that are not generally known.

Military Events.—Summary of the remarkable military events of which the ground has been the theatre, such as battles, combats, sieges, &c. Circumstances which historians generally known should have passed over, or which lack exactitude. Sources from which the information has been extracted.

CHAPTER XI.

ENSEMBLE OF THE OPERATIONS OF GEODESY.

(142.) The purpose of geodesy (5) is to make the triangulation of large extents of land.

The principles upon which the operations of geodesy are performed are the same as those of topography, but their application presents greater difficulties and requires the use of much more precise instruments.

(143.) The measurement of the bases is perhaps the most delicate of all these operations, it implies :

1. Direct measurement with standard measures ;
2. Reduction of the dimensions actually measured at various temperatures to the temperature of 64° ;
3. Reduction of the base thus corrected to the horizon ;
4. Reduction to the level of the sea.

(144.) As for the triangles, when the country does not afford eligible points, such as public buildings, steeples, &c., for their vertices, others are established by means of permanent signals.

The length of the bases rarely exceeds 6 or 7 miles, but the sides of the triangles may be 12 or 18 miles, and only occasionally more, as in the survey of Ireland, where sides of 70 to 90 miles have been used.

These large triangles form what is called the triangulation of the first order.

Their surface is decomposed into smaller triangles forming the triangulation of the second order, whose sides rarely exceed 10 or 15 miles.

Again those are subdivided into minor ones, constituting the triangulation of the third order.

(145.) The angles are measured with a theodolite or other precise

instrument, and their value is derived from several observations, the mean of which is calculated.

Several corrections are necessary :

1. Reduction to the centre of the station.
2. Reduction to the horizon, whenever another instrument than a theodolite is employed.
3. Correction due to the excentricity of the inferior telescope when using a circumferentor: this being very small is often neglected.

(146.) The triangles are afterwards calculated, but as they are spherical, their solution would necessitate the transformation of the bases into angular measure, to avoid which we calculate the triangles as rectilinear, either in correcting them of the spherical excess or replacing the arcs by their chords. The sum of the three angles of a spherical triangle is greater than 180° ; we subtract $\frac{1}{3}$ this excess from each angle, and with the three angles thus corrected we construct a rectilinear triangle the sides of which are equal to those of the spherical figure.

(147.) The altitude of the stations of the triangulation are also determined.

The absolute height above the mean level of the sea may be ascertained with the barometer, or by observing the dip of the sea. Knowing the altitude of one station, the altitudes of the different points can be found by measuring the complements of the angles of elevation, or zenithal distances.

These angles are corrected of the effects of refraction and curvature, and are also reduced to the summit of the signals.

Several other methods are also employed to obtain the difference of level. In observing simultaneously, for instance, two reciprocal zenithal distances, the correction due to the refraction may be dispensed with.

For the points of the minor triangulation, the observation of a single zenithal distance is sufficient, but the correction is indispensable.

(148.) The position which the triangulation occupies on the surface of the earth is obtained by measuring the latitude and longitude of one station at least, and also the azimuth of a side.


The latitudes, longitudes, and azimuths of the other points and lines are calculated, taking into consideration the spheroidal form of the globe.

(149.) Finally, to plot this triangulation, when it extends over a great surface, it becomes necessary to adopt a system of projection, since the surface of the earth cannot be developed on a plane, and to make the calculations that will give the geographical coordinates of the different points.

We may conclude with the most important corrections alluded to.

Limit of the Base.—Let the equilateral figure $a b c$ represent a triangle of the triangulation, and $a b$ the base b . The measure of the angles a and b being liable to an error of reading α , if we suppose

FIG. 153.



this error to take place in the same direction, the vertex c is displaced of a distance $c c' = E$. Now in triangle $a c c'$ we have:

$$c c' : c a :: \sin c a c' : \sin c c' a ;$$

$$\text{hence } \frac{E}{b} = \frac{\sin \alpha}{\sin c c' a} ; \text{ but } c c' a = 180^\circ - \left(\frac{C}{2} + \alpha \right)$$

$$\text{therefore } \sin c c' a = \sin \left(\frac{C}{2} + \alpha \right) = \sin \frac{C}{2} \text{ very nearly, since } \alpha \text{ is very small.}$$

$$\text{Then } \frac{E}{b} = \frac{\sin \alpha}{\sin \frac{C}{2}}, \text{ and as } C = 60^\circ, \sin \frac{C}{2} = \frac{1}{2} ;$$

$$\text{therefore } \frac{E}{b} = 2 \sin \alpha, \text{ and } b = \frac{E}{2 \sin \alpha}$$

If in this formula we replace E by its value (9) depending on the scale, and a by the approximation given by the angular instrument, the length of the base is found.


The same formula permits to know the degree of precision of the angular instrument to employ when the length of the base is given,

$$\sin a = \frac{E}{2b}$$

Again, if the base is given, and the instrument is also furnished to us, the formula $E = 2b \sin a$ indicates the degree of reliance to be placed in the plan.

(151.) *Reduction to the Centre.*—It frequently happens that we cannot place ourselves in the centre A or axis of the station from which we have to measure the angle subtended by two objects, C and B .

FIG. 154.



We then station near it in O , and measure the angle COB instead of CAB , and when the survey must be accurate, a correction becomes necessary. Let us find the difference $CAB - COB$ which represents this correction:

Measure the distance $AO = r$, and angle $COA = y$, let $AB = l$, $CA = l'$, $CAB = A$, $COB = O$, $ABO = B$, $OCA = C$.

The angle CHB exterior to the triangles CAH , HOB , is equal to the two interior and opposite angles,

$$CHB = OCA + BAC = ABO + COB$$

$$\text{hence } CAB - COB = ABO - OCA, \text{ or } A - O = B - C \text{ (1).}$$

But in triangle C A O we have $\frac{\sin C}{\sin y} = \frac{r}{l'}$

in triangle B A O $\frac{\sin B}{\sin (O+y)} = \frac{r}{l}$

therefore $\sin C = \frac{r \sin y}{l'}$ and $\sin B = \frac{r \sin (O+y)}{l}$

As the angles C and B are small we may replace them by their sines in (1).


hence $A - O = \sin B - \sin C = \frac{r \sin (O+y)}{l} - \frac{r \sin y}{l'}$

or in seconds $A - O = \frac{r}{\sin l'} \left(\frac{\sin (O+y)}{l} - \frac{\sin y}{l'} \right)$

The distances l and l' are given by the triangulation, and O, y, r have been accurately measured. The angle y is usually taken from left to right. Attention should be paid to the sign of the sines of $O+y$ and y , since the correction may be positive or negative.

(152.) *Reduction of an angle to the Horizon.*—Let $D O C$ be the angle observed between two objects C, D from the station O . As they are in a plane inclined to the horizon, the angle $D O C$ should be reduced to $A O B$.

FIG. 155.



Through O draw the vertical $O Z$ and describe with equal radii the arcs $Z A, Z B$.

The angle we search is $D Z C$ or its measure $A B$.

Observe the angles of elevation $B O C = h, A O D = h$.

Represent $D O C$ by α , and $A O B$ by A .

The spherical triangle Z D G gives

$$\cos A = \frac{\cos a - \sin h \sin h'}{\cos h \cos h'}$$

$$\text{hence } \cos a - \cos A = \frac{\sin h \sin h' - \cos a (1 - \cos h \cos h')}{\cos h \cos h'} \quad (1).$$

But,

$$\cos a - \cos A = 2 \sin \frac{1}{2} (A + a) \sin \frac{1}{2} (A - a)$$

$$\sin h \sin h' = \frac{1}{2} \cos (h - h') - \frac{1}{2} \cos (h + h') = \sin^2 \frac{1}{2} (h + h') - \sin^2 \frac{1}{2} (h - h')$$

$$\cos h \cos h' = \frac{1}{2} \cos (h + h') + \frac{1}{2} \cos (h - h')$$

$$1 - \cos h \cos h' = \sin^2 \frac{1}{2} (h + h') + \sin^2 \frac{1}{2} (h - h')$$

Substituting these values in (1) and replacing $\sin \frac{1}{2} (A + a)$ by $\sin a$ nearly equal to it, we have :


$$\begin{aligned} 2 \sin \frac{1}{2} (A - a) &= \frac{\sin^2 \frac{1}{2} (h + h') \left(\frac{1 - \cos a}{\sin a} \right) - \sin^2 \frac{1}{2} (h - h') \left(\frac{1 + \cos a}{\sin a} \right)}{\cos h \cos h'} \\ &= \frac{\sin^2 \frac{1}{2} (h + h') \text{ tang. } \frac{1}{2} a - \sin^2 \frac{1}{2} (h - h') \text{ cot. } \frac{1}{2} a}{\cos h \cos h'} \end{aligned}$$

and replacing the sines of the small angles $A - a$, h , and h' by their arcs, and observing that $\cos h \cos h'$ is sensibly = 1. The correction

$$= A - a = \left\{ \left(\frac{h + h'}{2} \right)^2 \text{ tang. } \frac{1}{2} a - \left(\frac{h - h'}{2} \right)^2 \text{ cot. } \frac{1}{2} a \right\} \frac{\sin 1''}{1''}$$

(153.) *Correction due to the Refraction.*—A ray of light passing through the atmosphere is deviated or refracted. The rays coming

FIG. 156.



from an object B instead of following the straight line B A are refracted according to a curve B A, concave towards the earth, and the eye placed in A will perceive the object on the direction A B' of

the last element of that curve. It follows that the effect of refraction is to give too great angles of elevation; therefore the altitude we observe should be corrected of the error BB' .

Let r represent the angle $B'AB$, O the angle AOB , d the distance AB , and R the terrestrial radius.

It has been found by experiments that the ratio between the angles r and O is constant; designing this ratio by p , we may write $\frac{r}{O} = p$, $r = p O$.

In triangle BAB' , the angle B being nearly right, $BB' = AB \text{ tang. } r = d \text{ tg. } r$, or $= d r$, since the tangent of angle r , on account of the small amplitude, can be replaced by its arc.

Therefore $BB' = d p O$. (1)


But in triangle ABO , which can be supposed right angled in A , $AB = AO \text{ tang. } O$, $d = R \text{ tang. } O$, or $d = R O$, since the amplitude of O is small.

Substituting the value of $O = \frac{d}{R}$ derived from this relation in (1), we have $BB' = \frac{p d^2}{R}$, and as p has been found to be $= \frac{1}{15}$,

The correction $BB' = \frac{d^2}{12 R}$ should be subtracted from the altitude obtained.

(154.) *Correction due to the curvature of the earth.*—Let B represent an object, observed from a station A .

FIG. 157.



To obtain the difference of level between A and B , we imagine the horizontal line AC , which is called the apparent level, to dis-

tinguish it from the true level A D. Therefore we obtain B C instead of B D, for the difference of level required.

In order to find the correction C D, let us observe that C A being the horizon of A, is tangent in that point; therefore—

A C' = C M. C D, and representing by R, the radius of the earth, by h the correction, and by D the distance A C, we have—

$$D^2 = (2R + h)h = 2Rh + h^2,$$

but h being very small, its square can be neglected, and $D^2 = 2Rh$,

$$\text{therefore } h = \frac{D^2}{2R}$$

(155.) *Levelling with the barometer.*—The height of the mercurial column in a barometer rises or falls when the instrument is carried below or above the level of the sea. The difference of level of two stations can be obtained by observing the relative height of the mercury in two barometers.

To proceed with exactitude, two observers simultaneously station at the points the difference of level of which is to be ascertained. They measure the mercurial height, the temperature of the barometer, and that of the atmosphere. They repeat their observations every fifteen minutes, and after two or three hours they compare their results, and, by means of a formula, deduct the difference of altitude. When there is only one observer, he should make a greater number of observations at each station, endeavouring to place himself in identical atmospheric circumstances.

The formula, taken from Bailey's Astronomical tables, is—

$$x = [60345.51 \{1 + .00111111 (t + t' - 64)\}] \times \text{Log} \left[\frac{\beta}{\beta'} \times \frac{1}{1 + .001(z - z')} \right] \times [1 + .002695 \cos 2 \phi.]$$

In which x = the difference of altitude expressed in feet.

t = temperature of the air.

z = temperature of the mercury.

β = height of the mercurial column.

t', z', β' , the corresponding measurements at the upper station.

ϕ = the latitude of the place.

} at the lower station.

This formula has been converted into tables, and we extract the following from Williams's "Practical Geodesy."

TABLE for determining Altitudes by the Barometer. Computed by MR. HOWLETT from the Formula given by MR. BAILEY.

Attached Thermometers.			Detached Thermometers.								Latitude of the place.	
D.	B.		S.	A.	S.	A.	S.	A.	S.	A.	L.	C.
	Therm. higher at lower station.	Therm. lower at lower station.										
0°	0.0000000	0.0000000	40°	4.7689067	75°	4.7859208	110°	4.8022936	145°	4.8180714	0°	0.0011689
1	0.0000434	9.9999566	41	4.7694021	76	4.7863973	111	4.8027525	146	4.8185140	3	0.0011624
2	0.0000869	9.9999131	42	4.7698971	77	4.7868733	112	4.8032109	147	4.8189569	6	0.0011433
3	0.0001303	9.9998697	43	4.7703911	78	4.7873487	113	4.8036687	148	4.8193975	9	0.0011117
4	0.0001737	9.9998262	44	4.7708851	79	4.7878236	114	4.8041261	149	4.8198387	12	0.0010679
5	0.0002171	9.9997828	45	4.7713785	80	4.7882979	115	4.8045830	150	4.8202794	15	0.0010124
6	0.0002605	9.9997393	46	4.7718711	81	4.7887719	116	4.8050395	151	4.8207196	18	0.0009459
7	0.0003039	9.9996959	47	4.7723633	82	4.7892451	117	4.8054953	152	4.8211594	21	0.0008689
8	0.0003473	9.9996524	48	4.7728548	83	4.7897180	118	4.8059509	153	4.8215988	24	0.0007825
9	0.0003907	9.9996090	49	4.7733457	84	4.7901903	119	4.8064068	154	4.8220377	27	0.0006874
10	0.0004341	9.9995655	50	4.7738363	85	4.7906621	120	4.8068604	155	4.8224761	30	0.0005848
11	0.0004775	9.9995220	51	4.7743261	86	4.7911336	121	4.8073144	156	4.8229141	33	0.0004768
12	0.0005208	9.9994785	52	4.7748153	87	4.7916042	122	4.8077680	157	4.8233517	36	0.0003615
13	0.0005642	9.9994350	53	4.7753042	88	4.7920745	123	4.8082211	158	4.8237888	39	0.0002432
14	0.0006076	9.9993916	54	4.7757925	89	4.7925441	124	4.8086737	159	4.8242266	42	0.0001223
15	0.0006510	9.9993481	55	4.7762802	90	4.7930135	125	4.8091258	160	4.8246618	45	0.0000000
16	0.0006943	9.9993046	56	4.7767674	91	4.7934822	126	4.8095776	161	4.8250976	48	9.9998775
17	0.0007377	9.9992611	57	4.7772540	92	4.7939504	127	4.8100287	162	4.8255331	49	9.9998372
18	0.0007810	9.9992176	58	4.7777400	93	4.7944189	128	4.8104795	163	4.8259680	50	9.9997967
19	0.0008244	9.9991741	59	4.7782256	94	4.7948854	129	4.8109298	164	4.8264034	51	9.9997566
20	0.0008677	9.9991305	60	4.7787105	95	4.7953521	130	4.8113796	165	4.8268365	52	9.9997167
21	0.0009111	9.9990870	61	4.7791949	96	4.7958184	131	4.8118290	166	4.8272701	53	9.9996772
22	0.0009544	9.9990435	62	4.7796788	97	4.7962841	132	4.8122778	167	4.8277084	54	9.9996381
23	0.0009977	9.9990000	63	4.7801622	98	4.7967493	133	4.8127263	168	4.8281362	55	9.9995995
24	0.0010411	9.9989564	64	4.7806450	99	4.7972141	134	4.8131742	169	4.8285685	56	9.9995613
25	0.0010844	9.9989129	65	4.7811272	100	4.7976784	135	4.8136216	170	4.8290005	57	9.9995237
26	0.0011277	9.9988694	66	4.7816090	101	4.7981421	136	4.8140688	171	4.8294319	58	9.9994866
27	0.0011710	9.9988258	67	4.7820902	102	4.7986054	137	4.8145153	172	4.8298629	59	9.9994502
28	0.0012143	9.9987823	68	4.7825709	103	4.7990681	138	4.8149614	173	4.8302937	60	9.9994144
29	0.0012576	9.9987387	69	4.7830511	104	4.7995303	139	4.8154070	174	4.8307288	63	9.9993115
30	0.0013009	9.9986952	70	4.7835306	105	4.7999921	140	4.8158523	175	4.8311536	66	9.9992161
31	0.0013442	9.9986516	71	4.7840098	106	4.8004533	141	4.8162970	176	4.8315830	69	9.9991293
			72	4.7844883	107	4.8009142	142	4.8167413	177	4.8320119	75	9.9990352
			73	4.7849664	108	4.8013744	143	4.8171852	178	4.8324404	81	9.9989384
			74	4.7854438	109	4.8018343	144	4.8176285	179	4.8328686		

The logarithm of the first term is contained in column A, by reading in column S the number corresponding to (t+t').

The logarithm of the last term is obtained from column C, taking the number corresponding to the latitude of the place of observation as given in column L.

As for the middle term, the column B gives the log of the factor.

$\frac{1}{1 + .0001(z - z')}$ by taking the number corresponding to the difference (z - z') as given in column D, the number in the left-hand column B being taken when the thermometer is higher at the lower station, and the number in the right hand when the thermometer

is lower at the lower station. Calling M this middle term, we have $M = \log. \beta - (\log \beta' \times B)$ and the whole difference is observed by $\log x = A + C + \log M$.

COLONIAL AND FOREIGN LINEAL MEASURES,

WITH THEIR EQUIVALENTS IN THE BRITISH STANDARDS.

(Extracted from Chambers' Commercial Tables.)

Countries.	Lineal Measure.	Countries.	Lineal Measure.
	Imperial.		Imperial.
AUSTRALIA.	MEXICO
AUSTRIA	Foot, 12'45 inch.	NAPLES	Palmo, 10'38 inch.
	Mile, . 4'71 miles.		Mile, . 1'14 miles.
Austrian Italy, Milan	New Brunswick
Venice .	Foot, 13'68 inch.	Newfoundland
BADEN	Foot, 11'81 "	NORWAY
BAVARIA	Foot, 11'67 "	NOVA SCOTIA
BELGIUM	PERSIA	Parasang 3'45 "
BRAZIL	PERU
BRUNSWICK. . . .	Foot, 11'23 "	POLAND	Foot, 11'34 inch.
BREMEN	Foot, 11'38 "		Mile, . 3'45 miles.
Buenos Ayres	PORTUGAL	Foot, 12'94 inch.
CANADA		League 8'84 miles.
Cape of Good Hope	PRUSSIA	Foot, 12'36 inch.
CHINA	Foot, 13'12 "		Mile, . 4'68 miles.
	Li, . 36 mile.	Prusso-German Com-
DEMERRARA.	mercial League or
DENMARK	Foot, 12'36 inch.	Zollverein . . .	Foot, 11'72 inch.
	Mile, . 4'68 miles.	Roman States . .	Mile, . '92 mile.
EGYPT	RUSSIA	Foot, 13'75 inch.
FRANCE	Pied usuel, 13'12 inch.		Verst, . '66 mile.
	Metre, . 39'87 "	SARDINIA	Mile, . 1'53 mile.
	Toise	GENOA . .	Palmo, 9'73 inch.
	usuelle 78'74 inch.	SAXONY	Foot, 11'15 "
	= 2 Metres.		Mile, . 5'63 miles.
	Kilometre, '62 mile.	SICILY	Palmo, 9'5 inch.
	= 1000 Metres.		Mile . 1'14 mile.
	Myriametre	SINGAPORE.
	6'21 miles.	SPAIN. . . .	Foot, 11'13 inch.
	= 10 Kilometres.		League, 4'21 miles.
Frankfort on the Maine	League 2'42 miles.	SWEDEN	Foot, 11'68 inch.
	Foot, 11'42 inch.		Mile, . 6'64 miles.
	Mile, . 4'60 miles.	SWITZERLAND . .	Foot, 11'81 inch.
GREECE		Mile, . 5'20 miles.
HAMBURG	Foot, 11'29 inch.	Geneva .	Foot, 19'21 inch.
	Mile, . 4'68 miles.	TURKEY	Berri, . 1'03 mile.
HANOVER	Foot, 11'45 inch.	TUSCANY	Foot, 21'58 inch.
	Mile, . 6'56 miles.		Mile, . 1'02 mile.
HOLLAND	Foot, 12'36 inch.	UNITED STATES
	Mijle, . '62 miles.	WEST INDIES (BRITISH)
INDIA	Mile Bengal 1'13 mile.	WURTEMBERG . .	Foot, 11'25 inch.
LUBEC	Foot, 11'35 inch.		
MALTA	Foot, 11'17 "		

1.— <i>Gradations admitting of Manœuvres.</i> (ACCORDING TO LEHMAN.)		
5°	10°	15°
<p>INFANTRY may move with order, and has, down hill, the most effectual fire and charge.</p> <p>CAVALRY may also move with order, and has, up hill, its most effectual shock.</p> <p>ARTILLERY has a more effectual fire down than up hill.</p>	<p>INFANTRY. Its close movements become more difficult.</p> <p>CAVALRY can only canter down hill, the charge possible only up hill.</p> <p>ARTILLERY moves with difficulty, its effectual and constant fire ceases.</p>	<p>INFANTRY cannot move any considerable distance with order; their fire up hill without effect.</p> <p>CAVALRY may still trot up, and walk down hill.</p> <p>ARTILLERY moves with great difficulty, its fire totally ceases.</p>
2.— <i>Gradations which may be ascended and descended singly.</i>		
20°	25°	30°
<p>INFANTRY cannot move in order, and can fire only singly with effect.</p> <p>CAVALRY may still ascend at a walk, and descend without order, and that only obliquely.</p>	<p>INFANTRY. Light Infantry as before.</p> <p>CAVALRY. Light Cavalry may ascend one by one obliquely, and descend in the same way, but with great difficulty.</p>	<p>INFANTRY. Chasseurs and Riflemen, as Light Infantry before.</p> <p>CAVALRY. Hussars may ascend as above, but with great difficulty, and when the slope is of soft earth.</p>
3.— <i>Gradations which may be climbed up.</i>		
35°	40°	45°
Chasseurs and Riflemen may ascend with difficulty one by one.	Chasseurs and Riflemen, without baggage, may ascend with help of their hands.	Chasseurs and Riflemen accustomed to hilly country may ascend as above, but with danger of falling.

MEMORANDUM ON TOPOGRAPHY FOR THE MILITARY COLLEGES.

THE following Scale of Shade and Instructions for representing ground in Military Plan Drawing, have been approved of by his Royal Highness the Field-Marshal Commanding-in-Chief, and have been introduced at the Staff College, the Royal Military College, and the Royal Military Academy.

SCALE.

Table showing the number of Strokes per inch, and the thickness of the strokes employed in the construction of the scale of shade.

Angle of Inclination.	No. of Strokes per inch.	Thickness of Strokes.
35°	32	$\frac{1}{32}$ inch
25°	32	$\frac{1}{70}$ „
20°	30	$\frac{1}{90}$ „
15°	26	$\frac{1}{110}$ „
10°	24	$\frac{1}{130}$ „
5°	18	$\frac{1}{200}$ „
3°	14	$\frac{1}{300}$ „
2°	12	$\frac{1}{400}$ „

From 35° to 45° the lines may increase in thickness according to the draughtsman's skill.

INSTRUCTIONS.

1. The shading produced by pen or pencil strokes drawn in accordance with the above scale, is to be based on contours traced at equal vertical intervals of 25 feet, or a convenient multiple thereof. All slopes exceeding 45° are to be shown as broken ground. The

interval between 45° and 35° (the latter being the highest grade provided for in Colonel Scott's scale) is to be filled with hachures of increased thickness.

2. The pen or pencil strokes are to be drawn on the horizontal system.

3. The shading so produced is to be proportioned to the slopes without reference to their altitudes above the sea; and none of the effects which would be caused by side illumination, are to be employed.

4. The contour lines used as the basis of the work are to be indicated by coloured, or, when that may be impracticable, by dotted lines, and they are to be marked by numbers representing their relative altitudes above a datum assumed, according to the character of the surrounding country, at 100, 500 or 1000 feet below the lowest point of the ground sketched.

5. The vertical intervals between the contours are to be notified in the margin of the plan, and also the distance of the assumed datum below the lowest point of the ground represented.

6. All the more important features are to be marked with bold figures in coloured ink, representing their order of position in altitude; the highest being marked 1.

7. When, owing to some peculiarity in the formation of the ground, the direction of the fall is not clearly apparent, arrow-headed lines are to be introduced pointing down the slope.

8. A scale of miles is to be drawn on every plan. This scale is to be sub-divided into portions, representing some convenient multiple of the English Yard.

WM. NAPIER, *Major-General,*

Vice-President, Council of

Military Education.

13, Great George Street, S.W.

23rd February, 1867.

INDEX.

- Aerography, 114.
Agriculture, 116.
Archæology, 122.
- Bardin (Professor), 18.
Base, 28.
Basin, 19.
Basins, 111.
Bearings, 49.
Bisecting an angle, 41.
Box sextant, 69.
Brushing with Indian ink, 18.
Buildings, 9.
- Canals, 119.
Cattle, 117.
Chaining, 80.
Clinometer, 80.
Clinometer Trinquier, 87.
Col, 19.
Colour, 8.
Commerce, 118.
Communications, 118.
Conditions to be fulfilled by a military survey, 7, 10.
Construction of scales, 31.
Contours, 10.
Conventional signs, 4, 7.
Co-ordinates, 94.
Correction due to the curvature of the earth, 129.
Correction due to refraction, 128.
Copy of plans, 23.
Counterforts, 20.
Coup d'œil militaire, 2.
Crest, 19.
Crimean survey, 14.
Cross staff, 75.
- Dales, 21.
- Declination, 56.
Defensive, 120.
Defiles, 20.
Diapasons, 16.
Distances, 30.
Distances reduced to the horizon, 35, 89.
- Echelle rapporteur, 57.
English systems, 17.
Equidistance, 12.
Error in reading, 5.
- Features of the ground, 19.
Filling in details, 27, 96, 104.
Finding the distance between two points, 38, 41, 75, 103.
Finding the direction of the capital of a bastion, 43, 55.
Finding the height of a building, 43.
Finding one's place in a survey, 54, 65.
Foreign linear measures, 132.
Form of triangles, 28.
French diapason, 15.
„ system, 13.
- Gardens, 9.
General configuration of the ground, 111.
„ history, 122.
Geodesy, 3, 128.
Geography, 3.
Geometrical representations, 11.
German systems, 15.
Guessing distances, 31.
- Hills, 20.
History, 122.
Horizontal style, 16.
Houses, 116.
Hydrography, 112.

- Industry, 117.
 Irregular survey, 2.
 Itinéraires, 109.
- Lakes, 9.
 Land communications, 118.
 Language, 114.
 Lehman's diapason, 16.
 Lehman's gradations, 133.
 Levelling, 3, 80.
 Levelling with barometer, 130.
 Levelling with plane table, 86.
 Light, 8.
 Limit of bases, 125.
 Limits of topography, 3.
- Magnetic azimuth, 49.
 Major Fèvre's table, 66.
 „ „ scale, 68.
 Making an angle equal to a given angle, 39.
 March of a survey, 91.
 Maritime navigation, 119.
 Materials, 116.
- Maximum dimensions of triangles, 29.
 Means of passing rivers, 119.
 Memoir, 102.
 Memorandum of the Council of Military Education, 134.
 Method of intersection, 54.
 Meridian line, 93.
 Military considerations, 120.
 „ events, 122.
 „ positions, 121.
 „ signs, 8.
 „ sketch, 2.
 „ sketching, 103.
 „ surveying, 1, 91.
 Militia, 115.
 Models, 1.
- Nature of the soil, 113.
 Navigation, 119.
 New scale of shade, 17.
- Oblique light, 18.
 Offensive, 120.
 Order to follow in copying plans, 24.
 Orography, 111.
- Perspective, 18.
 Physical description, 111.
 Plan, 2.
 Plane table, 59.
 Planimetry, 3.
 Plotting, 29.
 Polar star, 94.
 Political divisions, 114.
 Ponds, 9.
 Population, 114.
 Preliminary triangulation, 91.
 Prismatic compass, 49.
 Producing a direction beyond an obstacle, 40, 101.
 Profiles, 11.
 Protractors, 51.
 Public buildings, 115
 „ revenue, 118.
- Railroads, 9, 118.
 Ravine, 22.
 Reconnoitring, 2, 110.
 Reduction of an angle to the horizon, 127.
 Reduction of plans, 23.
 Reduction to the centre, 126.
 Religion, 115.
 Representation of the ground, 10.
 Resources for lodging troops, 116.
 Riding, 30.
 Rivers, 9.
 Roads, 9, 118.
- Scales, 4.
 „ usually employed, 6.
 „ for foreign plans, 34.
 „ for walking, trotting, or galloping, 34.
 Scott's diapason, 17.
 Sea-coasts, 113.
 Selection of a scale, 4.
 Shading, 13.
 Sight-rulers, 61.
 Sketching details, 104.
 „ the features of the ground, 98.
 Spherical excess, 124.
 Stadia, 31.
 Statistics, 114.
 Surveying with a chain, 46.
 „ „ plane table, 61.
 „ „ prismatic compass, 54.
 „ a polygon, 78.
 „ a road, 55.

- | | |
|--|--|
| <p> Surveying a river, 78.
 " a village, 96.
 Survey at sight, 106.
 " by memory, 109.

 Table-land, 19.
 Table of tangents, 82.
 Taking the back angle, 55.
 Telegraphic lines, 120.
 Thalweg, 21.
 Three methods of surveying, 27.
 Tithes-commissioners' signs, 7.
 Topography, 1.
 Topographical drawing, 7.
 Tracing contours, 99.
 " a direction on the ground, 36.
 " a parallel to a given line, 39, 64, 102.
 " a perpendicular to a given line 37, 74, 76. </p> | <p> Traversing, 55.
 Trees, 9.
 Triangulation, 26, 97, 123.
 Trigonometrical surveys, 123
 Trinquier, 57.

 Valuation of angles, 107.
 Valley, 21.
 Vernier, 70.
 Vertical style, 14.

 Water-level, 83.
 Watersheds, 19.
 Winkel-Kreutz, 108.
 Woods, 9, 117.

















































 Yeomanry, 116. </p> |
|--|--|

CONVENTIONAL SIGNS.

FOR THE SCALE OF 6 INCHES TO 1 MILE.

<i>Common Land.</i>	<i>Wood Land.</i>	<i>Coppice Wood.</i>	<i>Heath, Fern.</i>
<i>Plantations.</i>	<i>Coppice with Timber.</i>	<i>Rabbit Warrens and Sand Hills.</i>	<i>Parks.</i>
<i>Cultivated Fields.</i>	<i>Orchards.</i>	<i>Gardens.</i>	<i>Vineyards.</i>
<i>Meadows.</i>	<i>Hop Grounds.</i>	<i>Sand & Mud banks.</i>	<i>Rocks.</i>
<i>Land subject to inundations.</i>	<i>Cliffs.</i>	<i>Ozier Beds.</i>	<i>Undrained Marshes.</i>
			<i>Marshy Ground.</i>

CONVENTIONAL SIGNS.


	Scale of 6 in. to 1 m.	Scale of 3 in. to 1 m.
<i>Rail Roads</i>		
<i>Turnpike Roads</i>		
<i>Cross Roads</i>		
<i>Roads without Fences</i>		
<i>Roads with one Fence</i>		
<i>Bridle Roads</i>		
<i>Foot Paths</i>		
<i>Sunk Roads</i>		
<i>Raised Roads</i>		
<i>Rivers, Streams</i>		
<i>Lakes & Ponds</i>		
<i>Canals</i>		
<i>Drains</i>		
<i>Embankments</i>		
<i>Rope Walks</i>		
<i>Bridges</i>		
		
		
		
		
<i>Flying Bridges</i>		
<i>Ferries</i>		
<i>Fords</i>		
<i>Fish Weirs</i>		

Vincent Brooks, lith. London.


CONVENTIONAL SIGNS.

	Scale of 6 in. to 1 m.	Scale of 3 in. to 1 m.
<i>Earthen Fences</i>		
<i>Walls</i>		
<i>Rail Fences, Palings</i>		
<i>Hedges</i>		
<i>Hedges with Trees</i>		
<i>Lime Kilns</i>		
<i>Churches</i>		
<i>Houses and Farms</i>		
	(may be coloured Red)	(do.)
<i>Smithies</i>		
<i>Stone Windmills</i>		
<i>Wooden do.</i>		
<i>Watermills</i>		
<i>Iron Works</i>		
<i>Glass do.</i>		
<i>Light Houses</i>		
<i>Telegraphs</i>		
<i>Mercury</i>		do.
<i>Copper</i>		
<i>Lead</i>		
<i>Silver</i>		
<i>Gold</i>		
<i>Iron</i>		
<i>Tin</i>		
<i>Coal</i>		

Vincent Brooks, lith. London.





SECTIONS (SEE PLATE V.)
ON BASE LINES 1500 FT ABOVE THE SEA LEVEL.




Thames & Co. Lith. London


1, SCALE OF 3 INCHES TO 1 MILE.







SCALE OF 3 INCHES TO 1 MILE








MAJOR PETLEY'S SERIES.




Engraved by J. H. Stanger

MAJOR PETLEY'S SERIES.




Vincent Brooks lith. London.

MAJOR PETLEY'S SERIES.




Vincent. Brooks. lith London.




Vincent Brooks, lith. London.

MAJOR PETLEY'S SERIES.



Vincent Brooks lith London.

MAJOR PETLEY'S SERIES.



Amesbury, Mass. 1864.

**A MILITARY SKETCH
BY MAJOR PETLEY.**




Vincent Brooks sculp.

A MILITARY SKETCH
BY CAPTⁿ RICHARDS.




Vincent Brooks, lith. London.





SCALE OF 6 INCHES TO 1 MILE.

London Published June 1864 by Archley & Co 106, St. Russell St. W.C.




Vincent Brooks lith London

Scale of 6 inches to 1 mile.

Elevation on A B.






Vincent Brooks del. London.

Scale of 3 inches to 1 mile.

Elevation on A B.






Vincent Brooks lith London

Scale of 3 inches to 1 mile.


FROM THE QUARTER-MASTER-GENERAL'S
SURVEY IN THE CRIMEA.



Vincent Brooks lith. London.

SCALE OF 4 INCHES TO 1 MILE.

FROM PROFESSOR BARDIN'S SERIES.



SCALE 20,000


FROM PROFESSOR BARDIN'S SERIES.



SCALE 20,000



Vincent Brooks, lith. London.



Vincent Brooks Lith. London.


EYE SKETCH.

FROM WYLD'S MAP OF THE
WESTERN PYRENEES.

(ANALYTOGRAPH PROCESS)




AMCUT BROOKS, PHOTO-LITHO LONDON




Severn Valley, 1864



Vincent Brook, lith. London.



Vincent Brooks, Esq. London.




W. Jones & Co. Lith. London

Scale of 6 inches to 1 mile.



Scale of 3 inches to 1 mile.




Copyright © 1900, by the author.

Scale of 2 in. to 1 mile.



Scale of 1 in. to 1 m.




Scale of 3 inches to 1 mile.

PHOTO-LITHO OF THE ENGLISH
ORDNANCE SURVEY, (YORKSHIRE)




PHOTO-LITHO OF THE
FRENCH ORDNANCE MAP,
(PYRENEES)




Vincent Brooks, Photo-litho. London.

SCALE $\frac{1}{80,000}$




SCALE OF 3 INCHES TO 1 MILE.



Vincent Brooks, lith London.


SCALE OF 2 INCHES TO 1 MILE



Printed by W. G. Smith, London

Directions.


1. Copy that portion of this example which is below the line X Y in pen or pencil employing either vertical or horizontal strokes to shew the form of the ground, or if you prefer it, use the brush for its representation.
2. Draw Sections on the lines A B, C D, & E F, as accurately as you can.
3. Print the Title in the characters used on the example.
4. Give specimens of the manner in which you would represent woods, marshes, rocks & villages in a plan drawn to a scale of 10 000 or 300 yards to 1 Inch.



Instructions.

1. Copy the upper half of the plan in pen, pencil, or in brushwork, using a horizontal or vertical style of hatching as you may prefer.
The dotted lines shew Contours at 20 feet vertical intervals and will be found useful in making the Sections. Their suppression in the copy will not be considered to detract from its merit.
2. Draw a scale for the plan.
3. Draw Sections as accurately as you can on the lines A B, C D, E F.
4. Represent a marsh, a village, a sea beach & overhanging cliffs, & a wood suitable for the above scale.
5. Print the Title neatly in the characters given in the copy


EXAMPLE OF
ACCORDING TO COLON
(THE CHAIN-DOTTED COI



Mount Vesuvius, London


HILL SHADING,
SCOTT'S DIAPASON.
(HOURS ARE NOT FIGURED)

PLATE XL.




MAJOR PETLEY

157 E X
MANIPULATION







MPLE
EEHAND DRAWING






W. H. H. H.
Major

2ND E
SECTIONS AND




1

P L E
PONDING SHADES.




V. B. Day & Son
Major

3RD EX
SHOWING VARI.



PLE.
ONS IN SLOPES.




M. H. Day
Major

4TH

SHOWING CONTINUOUS DO


SCALE 6 IN. TO



AMPLE.

CONTOURS AT EQUAL DISTANCES

CONTOURS 25 FT




W. H. Smith
1890

5TH EX/


SHOWING DOTTED CONTOURS, SECTI

SCALE 6 IN⁵

In a finished Example dotted contours would be interpolated between the 200 feet contours on the gentler slopes, as in Example 6




5 1 MILE.





6TH EX

SHOWING CONTINUOUS




ARLE.

3 BROKEN CONTOURS.



V. B. Day
Major

AMPLE .



W. B. Day
W. B. Day

Vincent Brooks Day & Son, Lith.

1

1

1

1

1

1

1

1

1

1



THE
ARMY AND NAVY GAZETTE,
 AND
**JOURNAL OF THE MILITIA AND VOLUNTEER
 FORCES.**

EDITED BY W. H. RUSSELL, ESQ., LL.D.,

*Late Special Correspondent of THE TIMES during the Crimean War, the Indian Mutiny,
 and the American Campaign, &c. &c.*

Published every Saturday in time for despatch by the early Trains and Morning Mails.

REGISTERED FOR TRANSMISSION ABROAD—PRICE 6d., STAMPED 7d.

TERMS OF SUBSCRIPTION.

PAYABLE IN ADVANCE.

Per Annum	£1 10 4
Per Half-Year	0 15 2
Per Quarter	0 7 7

The name of the Editor justifies the expectation of the high literary excellence which characterizes the general writing and truthfulness of the Journal.

As a weekly chronicle of Naval and Military events, and of all matters of interest to the members of both Services, the GAZETTE forms an accurate and trustworthy work of reference; and on such special topics as the progress of the art of War, its opinions and digests are eagerly consulted.

Particular attention is called to the advantages possessed by the above Journal as a means of bringing Advertisements to the notice of the public. Its circulation is large, and is steadily increasing. The great influence it exercises in professional circles renders the paper a valuable medium for all who are desirous of the patronage of the Army, the Navy, the Volunteers, or of the great mass of general readers who consult its columns.

Advertisements cannot be separated from the body of the paper: the benefit derived from them, therefore, is of a lasting character.

The ARMY AND NAVY GAZETTE is filed regularly in all Clubs, Public and Government Offices, Mess-rooms, and News-rooms, and circulates largely amongst the nobility and general public. The GAZETTE therefore commands a far larger number of readers, and consequently a greater and more permanent influence, than many other papers which possess ten times the actual circulation of the GAZETTE.

PUBLISHED BY JAMES CLARKE,

AT 16, WELLINGTON STREET, STRAND, LONDON, W.C.,

And may be obtained of all Newsagents and Booksellers in Town and Country.

VANITY FAIR:

A WEEKLY SHOW

Political, Social, and Literary Wares.

With No. 16, which will be published this day, there will be given

A FULL-PAGE CARTOON

OF AN ENTIRELY NOVEL CHARACTER, PRINTED IN CHROMO-LITHOGRAPHY.

ORDERS and ADVERTISEMENTS received at the OFFICE, No. 27, Tavistock Street, Covent Garden, W.C.

THE BROAD ARROW

Is a Weekly Newspaper of Thirty-two pages for the

Military, Naval, and Civil Services.

It contains numerous original articles on Military and Civil affairs, Foreign Policy, and other subjects interesting to the Services of the country and the general reader, together with an epitome of the opinions of the contemporary press on similar subjects. There will also be found in each number full particulars of the Naval and Military intelligence of the week, derived from private correspondents at the various stations, as well as from more public sources.

New Inventions interesting to the Services are fully and fairly described; and a considerable space is devoted to the review of publications likely to prove interesting to the readers of the paper.

A List of the Stations of the Army and Navy, carefully prepared, is inserted once a month. And in every other respect the proprietors have attempted to make the BROAD ARROW a complete newspaper for the United Services.

With regard to politics and principles, the proprietors do not profess that the paper shall be neutral, or even what is conventionally called independent; but they desire to maintain its position as an impartial periodical, seeking to support no class-interest whatever inconsistent with the relative rights of all classes.

In supporting those who are invested with authority, the BROAD ARROW is not actuated by a desire to please those who possess power, and therefore will continue to comment freely upon what may appear to call for public criticism.

In advocating the interests of those who are placed under command, the BROAD ARROW has no desire to curry favour with the many, either for profit or popularity; and will not hesitate to condemn what may appear unjust claims or complaints.

It supports no cliqueism or professional prejudices. It desires to see the Army and Navy as the regular forces of the country, equal in efficiency to any other service in the world. And this it believes can be effected not through their depreciation by the ignorant, nor by their pretended reform through the corrupt and interested, but by the will of the nation unmistakeably declared in favour of justice to the Services, and inexorably demanding from them in return the efficient service they will then be bound to render.

The Militia is considered and treated in the BROAD ARROW as the main element of a reserve army, to be recruited by the ballot, and to be officered by civilians of local influence, thoroughly instructed.

The Volunteers are considered as men willing to be trained to arms at their own expense, as a condition of exemption from more arduous forced service in the Militia. They should be subjected at all times to discipline when in the ranks; officered by none who have not been proved fully competent for such a position, and who conscientiously continue to discharge the duties they have undertaken.

In the Civil branch of the Services there should not only be efficiency but ample and sure reward for the efficient, with protection for them against that system of favouritism which has hitherto been the main cause of whatever excess of expenditure and lack of efficiency may be chargeable against the Services.

The BROAD ARROW may be obtained Retail from all Booksellers and Newsagents; Wholesale from Messrs. SMITH and HUTTON 13, Catherine Street, Strand, and by Subscription 17s. 4d. per annum) from Mr. JAMES WEBSTER, 2, Waterloo Place, Pall Mall.

A simple copy may be obtained by remitting four postage stamps to Mr. JAMES WEBSTER.

TRÜBNER AND CO.'S MILITARY PUBLICATIONS.

- Barnard.**—*Notes on Sea Coast Defence*; consisting of Sea Coast Fortification, the Fifteen-Inch Gun, and Casemate Embrasures. By Gen. J. G. BARNARD, Corps of Engineers, U.S.A. *With one Plate.* 8vo, cloth, pp. 110. 9s.
- Benton.**—*A Course of Instruction in Ordnance and Gunnery.* Compiled for the use of the Cadets of the United States Military Academy. By Captain J. G. BENTON, Ordnance Department U.S.A. *Second Edition, revised and enlarged, with Engravings.* 8vo, pp. 550, half morocco. £1 4s.
- Cullum.**—*Systems of Military Bridges in use by the United States Army*, those adopted by the Great European Powers, and such as are employed in British India, with directions for the Preservation, Destruction, and Re-establishment of Bridges. By Brig.-Gen. GEORGE V. CULLUM. 8vo, cloth, *with Plates*, pp. 226. 21s.
- Gibbon.**—*The Artillerist's Manual.* Compiled from various sources, and adapted to the service of the United States. By Gen. JOHN GIBBON, U.S.A. *Illustrated with woodcuts and engravings. Second edition, revised and corrected, with valuable additions.* 8vo, half roan. 28s.
- Gillmore.**—*Engineering and Artillery Operations against the Defences of Charleston Harbour in 1863*; comprising the Descent upon Morris Island, the Demolition of Fort Sumter, the Reduction of Forts Wagner and Gregg. With Observations on Heavy Ordnance, Fortifications, &c. By Q. A. GILLMORE, Major of Engineers, and Commanding-General of the Land Forces engaged. With the Official Reports of Chief of Artillery, Assistant Engineers, &c. *Illustrated by 76 Plates and Engraved Views.* 8vo, cloth. £2 5s.
- Gillmore.**—*Practical Treatise on Limes, Hydraulic Cements, and Mortars*, containing Reports of numerous Experiments conducted in New York City during the years 1858 to 1861, inclusive. By Q. A. GILLMORE, A.M., Brig.-General of U.S. Volunteers, and Major U.S. Corps of Engineers. 8vo, cloth, pp. 333. 18s.
- Haupt.**—*Military Bridges*: with Suggestions of New Expedients and Constructions for Crossing Streams and Chasms. Including also Designs for Trestle and Truss Bridges for Military Railroads. Adapted especially to the wants of the Service in the United States. By HERMANN HAUPT, A.M., Civil Engineer. *Illustrated by 69 Lithographic engravings.* 8vo, cloth, pp. 329. 25s.
- Jomini.**—*The Military and Political Life of the Emperor Napoleon.* By Baron JOMINI, General-in-Chief and Aide-de-camp to the Emperor of Russia. Translated from the French, with Notes, by H. W. HALLECK, LL.D., Major-General U.S. Army. 4 vols. royal 8vo, cloth, *with an Atlas of 60 Maps and Plans.* 84s.
- Jomini.**—*The Political and Military History of the Campaign of Waterloo.* Translated from the French of General Baron DE JOMINI, by Captain S. V. Benét, United States Ordnance. *Third Edition.* 12mo, cloth. 6s.
- Jomini.**—*The Art of War.* By BARON DE JOMINI, General and Aide-de-camp to the Emperor of Russia. *A New Edition, with Appendices and Maps.* Translated from the French. By Capt. G. H. MENDELL and Capt. W. O. CRAIGHILL. Crown 8vo, cloth, pp. 410. 9s.
- Jomini.**—*Treatise on Grand Military Operations, or a Critical and Military History of the Wars of Frederick the Great, as contrasted with the modern system.* Together with a few of the most important principles of the Art of War. By Baron JOMINI, Commander-in-Chief, and Aide-de-camp to the Emperor of Russia. Translated from the French by Col. S. B. HOLABIRD, U.S.A. *Illustrated with Maps and Plans.* 2 vols. 8vo, cloth, pp. 448, 496; and an Atlas, containing 39 maps and plans of battles, 1741-1762. £3.
- Karcher.**—*Les Ecrivains Militaires de la France.* Par THEODORE KARCHER, Professeur à l'Académie Royale Militaire de Woolwich, &c. With numerous illustrations. 8vo, pp. 356, cloth. 7s. 6d.
- Mahan.**—*An Elementary Course of Military Engineering.* Comprising Field Fortification, Military Mining and Siege Operations. By D. H. MAHAN, LL.D., Professor of Military and Civil Engineering in the U.S. Military Academy. 8vo, cloth, 2 vols. 41s.
- Mahan.**—*An Elementary Course of Civil Engineering for the use of Cadets of the United States Military Academy.* By D. H. MAHAN, M.A. *New Edition, with large Addenda, and many new Cuts.* 8vo, cloth, pp. 410. 18s.
- Ordnance Manual,** for the Use of the Officers of the Army and others. Prepared under the direction of the War Department. *Third Edition.* 1 vol. demy 8vo. *Fully Illustrated.* 15s.
- Paterson.**—*Treatise on Military Drawing.* With a Course of 25 Progressive Plates. By Capt. W. PATERSON, Professor of Military Drawing at the Royal Military College, Sandhurst. Ob. 4to, pp. 44, cloth. 21s.
- Rebellion Record (The).** A Diary of American Events, 1860-64. Edited by FRANK MOORE. *Illustrated with Portraits, etc.* Vols. I. to II. 21s. each.
- Rodman.**—*Reports of Experiments on the Properties of Metals for Cannon, and the qualities of Cannon Powder, with an account of the Fabrication and Trial of a 15-inch Gun.* By Capt. T. J. RODMAN, of the Ordnance Department, U.S. Army. *Seventeen Plates.* 4to, cloth, pp. xii. and 308. 50s.
- Scott.**—*Military Dictionary*; comprising Technical Definitions; Information on Raising and Keeping Troops; Actual Service, including make-shifts and improved matériel, and Law, Government, Regulation, and Administration relating to Land Forces. By Colonel H. L. SCOTT, Inspector-General U.S.A. *Illustrated.* 8vo, half-morocco, pp. 674. 26s.

LONDON: TRÜBNER & CO., 60, PATERNOSTER ROW.

Second Edition, Corrected and Improved.

THE
OFFICE AND CABIN COMPANION,

FOR

ENGINEERS AND OFFICERS OF STEAM VESSELS;

*Consisting of Observations, Rules, and Tables, to Facilitate such Calculations
as Naval Officers and Engineers are called upon to make.*

BY J. SIMON HOLLAND,

ASSOC. L.N.A., CHIEF DRAUGHTSMAN TO THE STEAM BRANCH OF THE CONTROLLER OF THE NAVY'S DEPARTMENT;
FORMERLY CHIEF ENGINEER, R.N.

Price 5s. 6d., bound in cloth.

"Few men have had such excellent opportunities of finding out what naval officers and engineers require to have put into their hands as Mr. Holland, and few men would have known how to use them better than he. The appearance of his name on the title-page of the little work before us assured us that we had at last secured an engineer's pocket-book, or 'Cabin Companion,' as it is here called,

in which perfect clearness of treatment was combined with no less perfect accuracy in detail; and an examination of its pages entirely confirms our anticipation. So satisfied are we that the author has supplied a very necessary work in a very admirable manner, that we have no hesitation in predicting the almost universal use of this handbook among marine engineers and naval officers."—*Engineer*.

**THE ENGINEER'S POCKET REMEMBRANCER,
AN EPITOME OF DATA, RULES, AND FORMULÆ,**

*Applicable to Civil, Mechanical, Marine, Hydraulic, Light-House, Telegraphic,
Gas, and Railway Engineering, Surveying, etc.*

BY FRANCIS CAMPIN, C.E.,

Author of "A Practical Treatise on Mechanical Engineering," etc. etc.

Second Edition with Appendix, fcap. 8vo, cloth, 5s. 6d.

ATCHLEY & CO., ARCHITECTURAL, ENGINEERING, AND FINE ART PUBLISHERS,
106, GREAT RUSSELL STREET, BEDFORD SQUARE, W.C.

GENTLEMEN are invited to send for particulars and testimonials of our "PIN-CARTRIDGE" BREECH-LOADER at £10 10s., as useful as any gun at any price, and really good looking; excellent shooting guaranteed. This gun is made either in "Damascus" or "punched steel" barrels. Central-fire, in same quality, £3 3s. extra, fitted with an incomparable extractor.—J. & W. TOLLEY, Gunmakers, 22, St. Mary's square, Birmingham.
May be seen and tried at the Museum of Firearms, Peckham, London.

Breakfast—Grateful and Comforting.

EPPS'S COCOA.

PREPARED BY JAMES EPPS & CO., HOMŒOPATHIC CHEMISTS, LONDON.

Sold in tinned, labelled Packets, by the Trade in all Parts.

1



